

- ☐ SS/01- Branded Simple Set Reader with 2 *pre-learned keyfobs and a link*
- ☐ SS/01/UB- Unbranded Simple Set Reader with 2 *pre-learned Keyfobs and a link*
- ☐ SS/F - Branded keyfob
- ☐ SS/F/UB - Unbranded keyfob

Before you begin installation work do ensure you read these instructions.

- NOTE:** At least one keypad must be installed in the system. The keypad is necessary for manual operation of the system during normal use and for engineering it the during commissioning and maintenance.

The image contains two sets of technical drawings. The top set shows a 'Reader' device with a side view (22mm wide) and a front view (118mm wide, 84mm high). The front view includes buttons for Power, Day, Learn, Error, TA, and PA, a large oval display, and a 'ZONE' selector with eight numbered options. The bottom set shows a 'Keyfob' with a side view (58.5mm long) and a front view (18.5mm high).

**NOTE:** If you have additional keyfobs or have acquired new keyfobs to replace lost ones, then you will need to learn the keyfobs, see *how to learn* instructions.

**Base**

**Cable entry point**

**Mounting points**

**Tamper spring locating collar**

**Cover assembly**

**JUMPER**

**P2**

**RELAY**

**TAMP**

**SOUND**

**GOMMS**

**IV**

**WD1**

**Tamper Spring**


**Reader PCB (Board)**

**Tamper breakout**

**6-Thinned sections for cable entry**

**Cover fixing screw**

- ①** If required, cut-out the appropriate thinned section on the base for cable entry.
- ②** Route the external cable through the base and fix the base using the two mounting points.
- ③** Connect the external cable to the terminal block on the cover assembly, see also wiring diagrams.
- ④** Clip the cover assembly to the base and ensure the tamper spring locates into the collar **(A)** & **(B)**. Secure the cover assembly to the base using the cover fixing screw **(C)**.




Simple Set Reader and Keyfobs
Operating instructions

The reader mimics all the system indications given at other keypads in your system. The tamper indication is given by the indicator marked TA and personal attack by the indicator marked PA.

How to set the system

When you leave your premises you will need to set (or turn on) the intruder alarm system. Before setting the system you should ensure that the premises have been completely vacated and that all doors and windows are closed. Ensure that pets do not have access to the protected areas as they can cause a false alarm.



The Day indicator should be lit at the reader. Offer a keyfob to the reader and withdraw it as soon as you hear the keyfob recognition beep tone from the local sounder.

The system will now produce the exit beep tone and you should leave the premises by the exit route recommended by your installer. The system will set when the exit beep tone stops.


If you do not withdraw keyfob after it is recognised by the reader, you run the risk of entering the learn mode.

Once a set/unset operation is performed using the keyfob, wait for 5 seconds duration before next use of the keyfob to operate the system.

If you set/unset the system from a reader and subsequently unset/set the system using the keypad, then in some installations you may need to operate the system twice at the reader to allow the reader relay to catch up.

How to unset the system

When you enter your premises you will need to unset (or turn off) the system.



Enter your premises by the route recommended by your installer. The system will produce an entry beep tone.

Offer a keyfob to the reader and withdraw it as soon as you hear the keyfob recognition beep tone from the local sounder.


The system will stop the entry beep tone and light the green Day indicator.

If any Zone, Tamper or Attack indicator lights up then an alarm has occurred, and an intrusion may have taken place. Seek assistance before investigating further as intruders may still be on the premises. Then reset the system at the system keypad.







If you do not withdraw keyfob after it is recognised by the reader, you run the risk of entering the learn mode.

How to learn keyfobs if none are recognised

You will only need to learn keyfobs in this manner if no keyfobs are recognised by the reader. A reader can learn up to 8 keyfobs following power up of the intruder system. You must have all the keyfobs to be learnt available. Keyfobs can be learnt by each reader installed in a system



POWER UP THE SYSTEM
x 5 rapid beeps
JUMPER link removed



1 Ensure the reader is connected to the intruder system and the JUMPER link is fitted on the reader PCB.

Power up the intruder system and enter the User code at the system keypad to unset the system. You will hear five rapid beeps to acknowledge the reader is in the Learn mode. Remove the JUMPER link from the reader PCB.

The learn mode will NOT timeout until the first keyfob is learnt.

2 Hold the first keyfob slightly touching it on the centre depression of the reader. Once the first keyfob is acknowledged by the reader the ZONE 1 light changes from flashing to steady and there is a recognition beep given by the local sounder. Withdraw the learnt keyfob. The reader is now ready to learn the next keyfob, signalled by flashing of ZONE 2 indicator.

3 Offer the next keyfob slightly touching it on the centre depression of the reader. A learnt indication is given of the next keyfob when the flashing ZONE indicator changes to steady On indication and there is a recognition beep given by the local sounder. Shortly after the next numbered ZONE indicator starts flashing. Withdraw the learnt keyfob.



You now have up to 10 seconds to learn the next keyfob.

4 Repeat 3 to learn the next keyfob.





Once all the keyfobs are recognised 'learnt' by the Reader wait for just over 10 seconds and the reader will exit the learn mode, this is announced by two beeps from the local sounder and return to Day mode indication.

How to learn new keyfobs

Using a recognised learnt keyfob the reader can learn further keyfobs. A total of 8 keyfobs are recognised by a reader. You may want to do this if you have acquired additional keyfobs. Using these procedures the reader will still memorise previously learnt keyfobs. New keyfobs must be learnt by each reader installed in a system.



keyfob recognised beep
x 5 rapid beeps



1 Ensure the reader is in the day mode with the Day light lit. You should have one learnt keyfob and the new keyfobs available.

When an unrecognised keyfob is offered to the reader it will cause the Error light to be lit and continuous sound is emitted from the local sounder.

2 Hold the recognised 'learnt' keyfob such that it touches the centre depression on the Reader and keep it there without movement for 10 seconds. You will hear a keyfob recognition beep and 10 seconds later five rapid beeps from the local sounder. You are now in the learn mode. The Learn light will give a flashing indication and the ZONE lights change from flashing to steady On indication to show recognised or learnt keyfob. The reader is now ready to learn the new keyfobs signalled by the next flashing ZONE indicator. Withdraw the keyfob.

In the learn mode when an already learnt keyfob is offered to the reader, an Error indication will be given.

The learn mode will timeout after 10 seconds if no actions is taken to learn new keyfob

3 Offer the new keyfob slightly touch it on the centre depression of the reader. A learnt indication is given of the new keyfob when the flashing ZONE indicator changes to steady On indication and there is a recognition beep given by the local sounder. Shortly after the next numbered ZONE indicator will start flashing. Withdraw the learnt keyfob.








You now have up to 10 seconds to learn another new keyfob.

4 Repeat 3 to learn the new keyfob.

Once all the keyfobs are recognised 'learnt' by the reader wait for just over 10 seconds for the reader to exit the learn mode, this is announced by two beeps from the local sounder and return to Day mode indication.

How to re-learn all keyfobs

Using a recognised learnt keyfob the reader can re-learn up to 8 keyfobs. You may want to do this after a keyfob is lost or stolen and you want to prevent the use of it to operate the system. Keyfobs must be learnt by each reader installed in a system



By entering the learn mode in this manner you will erase all recognition of previously learnt keyfobs at the reader, except for the one used to enter the learn mode.

1 Ensure the reader is in the day mode with the Day light lit. You must have one learnt keyfob and up to 7 further keyfobs to be learnt. Have all the keyfobs available.

When an unrecognised keyfob is offered to the reader it will cause the Error light to be lit and continuous sound to be emitted from the local sounder.

2 Hold the recognised 'learnt' keyfob slightly touching the centre depression on the reader and keep it there without movement for 20 seconds. Initially you will hear a keyfob recognition beep and 10 seconds later five rapid beeps from the local sounder. After 20 seconds you will hear another keyfob recognition beep tone from the local sounder. You are now in the learn mode. The Learn light will give a flashing indication and the ZONE 1 light changes from flashing to steady On indication to recognise the learnt keyfob. The reader is now ready to learn the next keyfob, signalled by the flashing of ZONE 2 indicator. Withdraw the learnt keyfob.

In the learn mode when an already learnt keyfob is offered to the reader, an Error indication will be given.

The learn mode will timeout after 10 seconds if no actions is taken to learn the next keyfob

3 Offer the next keyfob slightly touch it on the centre depression of the reader. A learnt indication is given of the next keyfob when the flashing ZONE indicator changes to steady On indication and there is a recognition beep given by the local sounder. Shortly after the next numbered ZONE indicator will start flashing. Withdraw the learnt keyfob.

You now have up to 10 seconds to start learning the another keyfob.

4 Repeat 3 to learn the next keyfob.

Once all the keyfobs are recognised 'learnt' by the reader wait for just over 10 seconds for the reader to exit the learn mode, this is announced by two beeps from the local sounder and return to Day mode indication.

Fault finding

| Indication given..                     | what it means..                                                                                                                      | and what you could do.                                                               |
|----------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------|
| Error fast rate flash twice per second | The jumper link on the PCB has been left fitted following learn operation                                                            | Remove the jumper link and keep in safe place for future use.                        |
| Error slow rate flash 1s On and 1s Off | Non volatile memory (NVM) communication error                                                                                        | Re-learn all keyfobs and if problem persists then contact technical support for help |
| Error Error beep                       | You are using an already learnt keyfob during learn operation or you are offering an unlearnt keyfob to the reader during normal use | Offer an unlearnt or learnt keyfob respectively.                                     |

Registered installers should refer to their supplied contact details.

For Technical Support : 0906 302 0999

This is a premium rate line, calls are charged at 50 pence per minute.

Novar ED&S
The Arnold Centre
Paycocke Road
Basildon
SS14 3EA

The product conform to the requirements of the European EMC and Low Voltage directives, and carries the CE mark.

