


**PCE9220SS 90cm
Multi-function twin
cavity cooking theatre**

Instruction manual



User Manual for your Baumatic

PCE9220SS

90 cm Multi-function twin cavity cooking
theatre



NOTE: This User Instruction Manual contains important information, including safety & installation points, which will enable you to get the most out of your appliance. Please keep it in a safe place so that it is easily available for future reference; for you or any person not familiar with the operation of the appliance.

DD 29/10/07

Contents

Environmental note	4
Important safety information	5 – 9
Specifications	9 – 10
Thermostat control knob (main oven)	11
Oven function selector knob (main oven)	11
Oven function and thermostat control knob (secondary oven)	11
Oven programmer/timer	12
Oven programmer/timer display	12
Setting and using the oven programmer/timer	12 - 16
Selecting manual operation mode	12
Setting the time of day	12
Setting the minute minder function	13
Setting the duration function	14
Setting the end cook function	15
Setting the start and end time function	16
Selecting a cooking function and temperature	17 - 22
Selecting manual operation mode	17
Before first use	17
Selecting a main oven function	17 - 18
Thermostat control knob (main oven)	19
Selecting an oven function and temperature (secondary oven)	19
Oven operating light	19
Cooking guidelines	20
Warnings	20 – 21
Using and assembling the rotisserie	21 - 22
Using the ceramic hob top	22 - 25
Before first use	22
Using the hob top zones	22 - 23
Using the dual zone on the ceramic hob	23 - 24
Hob guidelines	24 - 25
Cleaning and maintenance	25 - 30
Cleaning the ceramic hob top	26
After each use	26
Cleaning table	26
Using a ceramic hob scraper	27
Using a specialist ceramic hob cleaner	27
Replacing the oven bulb	27 - 28
Removing the oven door for cleaning	28
Removing the inner door glass for cleaning	29 - 30
Installation	30 - 33
Positioning	30 – 32
Electrical connection	32
Connecting the main supply cable	33
Replacing the mains supply cable	33
My appliance isn't working correctly	34 – 35
Contact details	36

This appliance is marked according to the European directive 2002/96/EC on Waste electrical and Electronic Equipment (WEEE). By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product.

The symbol  on the product, or on the documents accompanying the product, indicates that this appliance may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

Disposal must be carried out in accordance with local environmental regulations for waste disposal.

For more detailed information about treatment, recovery and recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.



- o The packaging materials that Baumatic uses are environmentally friendly and can be recycled.
- o Please discard all packaging material with due regard for the environment.

Important safety information



Your safety is of the utmost importance to Baumatic. Please make sure that you read this instruction booklet **before** attempting to install or use the appliance. If you are unsure of any of the information contained in this booklet, please contact the Baumatic Technical Department.

General Information

- o This appliance is designed for domestic household use and for the cooking of domestic foodstuffs.
- o **IMPORTANT:** The adjacent furniture and all materials used in the installation **must** be able to withstand a minimum temperature of 85°C above the ambient temperature of the room it is located in, whilst in use.
- o Certain types of vinyl or laminate kitchen furniture are particularly prone to heat damage or discolouration at temperatures below the guidelines given above.
- o Any damage caused by the appliance being installed in contravention of this temperature limit, or by placing adjacent cabinet materials closer than 20 mm to the appliance, **will be the liability of the owner.**
- o For use in **leisure accommodation vehicles**, please refer to the appropriate information given in the installation instructions for this appliance.
- o **IMPORTANT:** Baumatic Ltd. **DO NOT** recommend that this appliance is installed on any type of marine vessel.
- o The use of this appliance for any other purpose or in any other environment without the express agreement of Baumatic Ltd. will invalidate any warranty or liability claim.
- o Your new appliance is guaranteed against electrical or mechanical defects, subject to certain exclusions that are noted in Baumatic's Conditions Of Guarantee. The foregoing does not affect your statutory rights.
- o **Repairs may only be carried out by Baumatic Service Engineers or their authorised service agent.**

Warning and safety instructions

- o This appliance complies with all current European safety legislation. Baumatic do wish to emphasise that this compliance does not remove the fact that the appliance surfaces **will become hot during use and retain heat after operation.**

Child Safety

- o Baumatic strongly recommend that babies and young children are prevented from being near to the appliance and not allowed to touch the appliance **at any time.** During and after use, all surfaces will become hot.
- o If it is necessary for younger family members to be in the kitchen, please ensure that they are kept under close supervision at all times.

General Safety

- ✓ Make sure that you understand the controls before using the appliance.
- ✓ Check that all of the controls on the appliance are turned off after use.
- ✓ Always stand back when opening the oven door, this will allow heat to disperse.
- ✓ Take care when removing items from the oven, as the contents may be hot.
- ✓ Always keep the oven doors closed when the oven is not in use.
- ✓ Always follow the basic principles of food handling and hygiene, this will prevent the possibility of bacterial growth.
- ✓ Always keep ventilation slots clear of obstructions.
- ✓ Keep fingers away from the hinge areas when closing the door, otherwise you may trap them.
- ✓ Oven gloves should be used when placing food in the oven cavity and when removing it. Care should be taken to avoid direct contact with any of the elements in the appliance.
- o **DO NOT LEAVE THE APPLIANCE UNATTENDED WHILST IN USE.**

- o **Do not** place heavy objects on the oven door or lean on the oven door when it is open, as this can cause damage to the oven door hinges. Nobody should be allowed to sit or stand on any part of the cooker.
- o **Do not** store chemicals, food stuffs, pressurised containers in or on the cooker or in cabinets immediately above or next to the cooker.
- o **Do not** heat up unopened food containers, as pressure can build up which may cause the container to burst.
- o **Do not** place flammable or plastic items on or near the hob burners, these types of materials should also not be placed in the oven or the compartment below the oven.
- o **Do not** leave heated oil or fat unattended, as this is a fire risk. You should not fill a deep fat frying pan more than one third full of fat or oil; you should also not use a lid.
- o **Do not** allow fat or oil to build up in the oven trays, grill pan or oven base.
- o **Do not** place pans or baking trays directly on the base of the oven cavity, or line it with aluminium foil.
- o **Do not** grill food containing fat without using the grill trivet. The grill trivet should never be covered with aluminium foil.
- o **Do not** place hot enamel parts in water, leave them to cool first.
- o **Do not** allow vinegar, coffee, milk, saltwater, lemon, tomato juice or any liquid with high sugar content to remain in contact with the enamel parts of the appliance. Spillages should be wiped up immediately.
- o **Do not** allow electrical fittings or cables to come into contact with areas on the appliance that get hot.
- o **Do not** use the appliance to heat the room it is located in or to dry clothing. No clothing should be placed over or near to the hob burners or oven door.
- o **Do not** install the appliance next to curtains or soft furnishings.

- o **Do not** attempt to lift or move cooking appliances by using the oven door or handle, as this may cause damage to the appliance or result in injury to the person lifting the appliance.

Cleaning

- o Cleaning of the oven should be carried out on a regular basis.
- o Great care should be taken whilst using this appliance and when following the cleaning procedure.
- o **IMPORTANT:** The appliance must be disconnected from the mains before following the cleaning procedure.
- o **IMPORTANT: Care must be taken when cleaning between the door glasses, and inside the inner frame as some of the edges maybe sharp due to the manufacturing process.**

Installation



This appliance must be correctly installed by a suitably qualified person, strictly in accordance with the manufacturer's instructions. Please see the specific section of this booklet that refers to installation.

- o **Baumatic Ltd. declines any responsibility for injury or damage, to person or property, as a result of improper use or installation of this appliance.**
- o Heat, steam and moisture will be created during use of the appliance, take care to avoid injury and ensure that the room is adequately ventilated. If the appliance is going to be used for prolonged periods of time, then additional ventilation may be required.
- o Please consult with your qualified installer if you are in any doubt about the amount of ventilation that you will require.


Declaration of conformity

This appliance complies with the following European Directives:

- 73/23/EEC regarding "low voltage"
- 89/336/EEC regarding "electromagnetic disturbances"
- 90/396/EEC regarding "gas appliances"
- 89/109/EEC regarding "materials in contact with food".

- o The above directives comply with 93/68/EEC regarding CE marking.
- o The manufacturer declares that the oven is built using certified materials and requires the appliance to be installed in accordance with the standards currently in force. This appliance must be used by a trained person for domestic purposes only.

Specifications



Product dimensions:

Height: 870 - 920 mm
Width: 898 mm
Depth: 600 mm

Product specifications:

- o **5 zone ceramic hob:**
 - o 1 x 1.40/2.20 kW hyperspeed oval zone (diameter 170/265 mm)
 - o 1 x 0.70/2.10 kW dual circuit hyperspeed zone (diameter 120/210 mm)
 - o 1 x 2.20 kW hyperspeed zone (diameter 210 mm)
 - o 2 x 1.20 kW hyperspeed zone (diameter 145 mm)
- o 8 function main oven
- o 5 function secondary oven
- o Oven energy efficiency class: B
- o Main oven capacity: 61 litres
- o Secondary oven capacity: 37 litres
- o Storage compartment capacity: 35 litres
- o LED fully programmable timer
- o 2 Cooling fans
- o Thermostatically controlled grills
- o Double glazed removable doors
- o Adjustable feet
- o Rotisserie skewer with removable handle

Standard accessories:

- o Removable side racks
- o 3 x Safety shelves
- o 2 x Enamelled drip trays without handle
- o 2 x Trivet

Optional extras:

- o BPS1 Pizza stone

Electrical details

Rated Voltage:	230 Vac 50 Hz
Supply Connection:	32 A (double pole switched fused outlet with 3mm contact gap)
Max Rated Inputs:	12.48 kW
Mains Supply Lead:	3 core x 6 mm ² (not supplied)
Oven Light Bulb:	E14 15 W/300°C screw type pigmy


For future reference please record the following information which can be found on the rating plate and the date of purchase which can be found on your sales invoice. The rating plate for your oven can be located by opening the door of the storage compartment.

Model Number

Serial Number


Date of Purchase

Thermostat control knob (main oven)




- o Use this control knob to control the temperature in the oven.

Oven function selector knob (main oven)




- o Use this control knob to select the oven function and turn on the oven light in the main oven.

Oven function and thermostat control knob (secondary oven)




- o Use this control knob to select the oven function and turn on the oven light in the secondary oven.

Oven programmer / timer



Oven programmer / timer display



- 7) "Auto" function symbol
- 8) "Minute minder" symbol
- 9) "Manual operation" symbol.

Setting and using the oven programmer / timer

Selecting manual operation mode

After your appliance is connected to your mains supply for the first time, the numbers on the timer display will flash. Before you can select a cooking function or set a temperature, you must set the appliance into "manual operation" mode.

- o To select manual operation mode, press the "manual operation" button **(4)** on the control panel.

Setting the time of day

After setting your oven for manual operation, you should also set the time of day.

- o Use the "minus" button **(5)** and "plus" button **(6)** to adjust the time that appears in the display. After getting the display to the correct time, release the "minus" and "plus" buttons. After a few seconds the time will fix in the display and you will be able to use your oven.

Setting the minute minder function (main and secondary oven)

You are able to set the minute minder at any time, regardless of whether an oven function has been selected. You can set a period of time using the minute minder function and an alarm will sound when this period of time has elapsed.

- o Press the “minute minder” button **(1)**, the display will show a value of 00:00. Set the period of time that you wish the minute minder to countdown for, by using the “minus” **(5)** and “plus” **(6)** buttons.
- o Once the display has got to your desired countdown time, let go of the “minus” and “plus” buttons. The minute minder symbol **(8)** will appear on the timer display.
- o Once a countdown time has been set, it is possible to shorten or lengthen the time by using the “minus” **(5)** or “plus” **(6)** buttons.
- o An alarm will sound when the countdown time has elapsed. The alarm can be silenced by pressing the “minute minder” button **(1)**.
- o **Important:** The oven will continue to heat once the alarm has been silenced. If you have finished cooking, then you should turn the oven function selector and thermostat control knob to 0.

Setting the duration function (main oven only)

This function will allow you to set a countdown time similar to the minute minder function. However the oven will no longer continue to heat, once the countdown period has elapsed.

- o Use the thermostat control knob to set the temperature that you require. The manual operation symbol **(9)** will appear on the display.
- o Use the oven function selector knob to select the mode of cooking that you require.
- o It is then possible to set the duration of the cooking time that you require.
- o Press the “duration” button **(2)** and the display will show a value of 00:00. Set the period of time that you wish the duration function to countdown for, by using the “minus” **(5)** and “plus” **(6)** buttons.
- o Once the display has got to your desired countdown time, let go of the “minus” and “plus” buttons. The countdown will start immediately and the word AUTO **(7)** will appear on the timer display.
- o Once a countdown time has been set, it is possible to shorten or lengthen the time by using the “minus” or “plus” buttons.
- o An alarm will sound when the countdown time has elapsed and the oven will switch off. The word AUTO will flash and the heating symbol will disappear. The alarm can be silenced by pressing the “duration” button **(2)**.
- o You will need to return the oven to manual operation mode, once the duration function has been used. To do this you should press the “manual operation” button **(4)**, the word AUTO will disappear from the display and the manual operation symbol will appear instead.
- o **Important:** If you do not turn the thermostat control knob and oven function selector knob to 0. Then the appliance will continue to operate as soon as you press the “manual operation” button.

Setting the end cook function (main oven only)

This function is similar to the duration function, however instead of selecting a period of time that you wish the oven to switch off after. You select the time of day that you wish the oven to switch off at.

- o Use the thermostat control knob to set the temperature that you require. The manual operation symbol **(9)** will appear on the display.
- o Use the oven function selector knob to select the mode of cooking that you require.
- o Press the “end cook” button **(3)** and the display will show a value of 00:00. Set the time of day that you wish the oven to stop cooking at by using the “minus” **(5)** and “plus” **(6)** buttons. The timer will calculate how long the cooking time will be, based on the time of day that you have selected and show it on the display.
- o Once the display has got to the time of day that you want the oven to stop cooking at, let go of the “minus” and “plus” buttons. The countdown will start immediately and the word AUTO **(7)** will appear on the timer display.
- o When the time is set, it can be modified by pressing the “minus” and “plus” buttons.
- o When the time of day reaches the end of cooking time that you set, the oven will switch off and an alarm will sound. The word AUTO will flash and the heating symbol will disappear. The alarm can be silenced by pressing the “end cook” button.
- o You will need to return the oven to manual operation mode, once the end cook function has been used. To do this you should press the “manual operation” button **(4)**, the word AUTO will disappear from the display and the manual operation symbol will appear instead.
- o **Important:** If you do not turn the thermostat control knob and oven function selector knob to 0. Then the appliance will continue to operate as soon as you press the “manual operation” button.

Setting the start and end time function (main oven only)

This function will allow you to set a time in the future that the oven switches on at and a time that the oven will switch off at.

- o Use the thermostat control knob to set the temperature that you require. The manual operation symbol **(9)** will appear on the display.
- o Use the oven function selector knob to select the mode of cooking that you require.
- o Press the “duration” button **(2)** and the display will show a value of 00:00. Set the period of time that you wish to cook for, by using the “minus” **(5)** and “plus” **(6)** buttons. The word AUTO **(7)** will appear on the timer display.
- o **Immediately** press the “end cook” button **(3)** and the timer display will show a value of 00:00. Set the time of day that you want the oven to switch off at, using the “minus” **(5)** and “plus” **(6)** buttons.
- o The oven will calculate what time it needs to switch on at, so that your food will cook for the length of time that you selected. It will automatically switch itself on, once it reaches the time of day that it has calculated.
- o When the time of day reaches the end of cooking time that you set, the oven will switch off and an alarm will sound. The word AUTO will flash and the heating symbol will disappear. The alarm can be silenced by pressing the “end cook” **(3)** or “duration” button **(2)**.
- o You will need to return the oven to manual operation mode, once the start and end time function has been used. To do this you should press the “manual operation” button **(4)**, the word AUTO will disappear from the display and the manual operation symbol will appear instead.
- o **Important:** If you do not turn the thermostat control knob and oven function selector knob to 0. Then the appliance will continue to operate as soon as you press the “manual operation” button.

Selecting a cooking function and temperature

Selecting manual operation mode


After your appliance is connected to your mains supply for the first time, the numbers on the timer display will flash. Before you can select a cooking function or set a temperature, you must set the appliance into “manual operation” mode.

- o To select manual operation mode, press the “manual operation” button **(4)** on the control panel.

Before first use

- o To remove any residue from the main oven that may have been left from the manufacturing process, you should select either the fan or conventional oven function and turn the thermostat dial to its maximum temperature setting. For the secondary oven you should select the conventional oven function and select its maximum temperature setting.
- o It is perfectly normal for a smell to be produced during this process.
- o You should make sure that any windows in the room are left open during this process.
- o It is advisable for you not to remain in the room whilst the burning off process is taking place.
- o You should leave each oven on maximum setting for 30 – 40 minutes.
- o **IMPORTANT: You should not burn off both ovens simultaneously.**

Selecting a main oven function



The main oven function selector knob should be turned clockwise and used to select the particular mode of cooking that you require. The appliance will utilise different elements within the oven cavity, depending on the oven function that you select. When a function is selected, the power indicator light will come on.

There are eight cooking functions available on your appliance:



OVEN LIGHT: Separate light control which allows the light to be switched on, even when the oven is not heating.



DEFROST MODE: The fan runs without heat to reduce the defrosting time of frozen foods. The time required to defrost the food will depend on the room temperature, the quantity and type of food. Always check food packaging for the defrosting instructions.



CONVENTIONAL OVEN (top and lower element): This method of cooking provides traditional cooking, with heat from the top and lower elements. This function is suitable for roasting and baking on one shelf only.



FAN OVEN: This method of cooking uses the circular element while the heat is distributed by the fan. This results in a faster and more economical cooking process. The fan oven allows food to be cooked simultaneously on different shelves, preventing the transmission of smells and tastes from one dish onto another.



HALF GRILL: This method of cooking utilises the inner part only of the top element, which directs heat downwards onto the food. This function is suitable for grilling small portions of bacon, toast and meat etc. The thermostat control knob must be turned to its maximum setting.



FULL GRILL: This method of cooking utilises the inner and outer parts of the top element, which directs heat downwards onto the food. This function is suitable for grilling medium or large portions of sausages, bacon, steaks, fish etc. Ideally the thermostat control knob should be set to 200°C




FAN AND GRILL: This method of cooking utilises the top element in conjunction with the fan, which helps to provide a quick circulation of heat. This function is suitable where quick browning is required and “sealing” the juices in, such as steaks, hamburgers, some vegetables etc.




FAN AND LOWER ELEMENT: This method of cooking utilises the bottom element in conjunction with the fan, which helps to circulate the heat. This function is suitable for sterilising and preserving jars.

Thermostat control knob (main oven)



The oven thermostat control knob should be turned clockwise and it sets the required temperature of the oven. It is possible to regulate the temperature within a range of 60 - 250°C.

Selecting an oven function and temperature (secondary oven)




If you turn the control knob clockwise, it will automatically select the oven light function first. If you continue turning the control knob, you will select the conventional oven function. You can regulate the conventional oven between a temperature of 60 - 250°C.

To use one of the other functions, you should turn the dial past the max. setting and select the following functions.



UPPER ELEMENT ONLY: This method of cooking uses the outer part of the top element to direct gentle heat downwards onto the food. For gentle cooking, browning or keeping cooked dishes warm.



LOWER ELEMENT ONLY: This method of cooking uses the lower element to direct heat upwards to the food. For slow-cooking recipes or for warming up meals.



GRILL ELEMENT ONLY: This method of cooking utilises the top element, which directs heat downwards onto the food. This function is suitable for grilling small portions of bacon, toast and meat etc.

Oven operating light

This light will come on to indicate that the oven's heating elements are in operation. The light will turn off when the temperature set on the thermostat control knob has been reached. It will cycle on and off throughout the cooking time.

You should not place food inside the cavity, until the correct cooking temperature has been reached.

Cooking guidelines


- o Please refer to the information given on food packaging for guidance on cooking temperatures and times. Once familiar with the performance of your appliance, temperatures and times can be varied to suit personal preference.
- o If you are using the fan oven function, then you should follow the information given on the food packaging for this particular mode of cooking.
- o Make sure that frozen foods are thoroughly thawed before cooking, unless the instructions on the food packaging advise that you can “cook from frozen”.
- o You should pre-heat the oven and not place food inside of it until the oven operating light has gone off. You can choose not to pre-heat when using the fan oven mode; however you should extend the cooking time given on the food packaging by approximately ten minutes.
- o Before cooking, check that any unused accessories are removed from the oven.
- o Place cooking trays in the centre of the oven and leave gaps between the trays to allow air to circulate.
- o Try to open the door as little as possible to view the dishes.
- o The oven light will remain on during cooking.

Warnings



- o Keep the oven door closed when using any of the grill or oven functions.
- o Do not use aluminium foil to cover the grill pan or heat items wrapped in aluminium foil under the grill. The high reflectivity of the foil could potentially damage the grill element.
- o You should never line the base of your oven with aluminium foil.
- o During cooking, never place pans or cookware directly onto the bottom of the oven. They should always be placed on the shelves provided.
- o The grill heating element becomes extremely hot during operation, avoid touching it inadvertently when handling the food which you are grilling.

- o **Important:** Be careful when opening the door, to avoid contact with hot parts and steam.
- o **IMPORTANT:** In case of fire, close the main valve of the gas supply and switch off the electricity supply to the appliance.
NEVER pour water onto burning oil.

Using and assembling the rotisserie



- o Place the food on the spit **(L)**, making sure that it is placed centrally between the two forks **(F)**. Otherwise excess strain will be placed on the motor **(R)**.
- o Place one end of the spit **(L)** onto support **(G)** and put the opposite end into the hole of the motor **(P)**.
- o Fill the drip tray with a little water and place this under the spit **(L)**.



- o Fit the grill deflector **(S)** into position and leave the door half way open.

- o Turn the Oven function and thermostat control knob (secondary oven) to the  symbol and then press the Rotisserie On/Off button.
- o To rotate the spit in the opposite direction, whilst wearing a protective oven glove, turn the rotation knob **(A)**.
- o Make sure that you press the Rotisserie On/Off button, then turn the Oven function and thermostat control knob (secondary oven) to 0 before attempting to remove the spit **(L)**.

Using the ceramic hob top

Before first use




IMPORTANT: You should clean the ceramic hob surface (see “Cleaning and maintenance” section).

- o You should switch on one cooking zone at a time, for 5 minutes at the maximum setting. This will help to eliminate any new smell that exists and evaporate any humidity that has formed on the heating elements during transit.
- o Do not burn off more than one zone at once.
- o **You must** place a saucepan filled half full with cold water on each zone as you burn it off.

Using the hob top zones

- o Each zone on the ceramic hob top is controlled by a control knob.



- o To activate a zone, position the control knob between 1 – 11.

- o A warning neon on the control panel will light, to indicate that a zone has been switched on.
- o Each zone has a residual heat indicator which will light when one or more of the cooking areas go above a temperature of 60°C.

- o You should select a control knob position that is suitable for the particular cooking that you are carrying out. See the table on the next page for guidance on the most appropriate control knob position.

Pos.	Heat Intensity	Use
0	Off	
1 - 2	Very slow	For melting butter, chocolate, etc. For heating small amounts of liquid.
3 - 4	Low	For heating larger amounts of liquid. For preparing slow-cooking creams and sauces.
5 - 6	Medium-Low	For thawing frozen foods and cooking stews, cooking at boiling or lower temperatures.
7 - 8	Medium	For boiling foods, roasting delicate meats and fish.
9 - 10	High	For braising chops and steaks, for large meat soups.
11	Very high	For boiling large amounts of water and frying.

- o When you have finished cooking on a particular zone, it is important to make sure that the control knob is turned back to 0 (the off position).
- o The warning light on the control panel will inform you if a cooking area is turned on or off.
- o The residual heat indicator will remain lit until the temperature of the cooking area has fallen below 60°C.

Using the dual zone on the ceramic hob

- o The central and front left zones on your hob top are dual zones.
- o To activate the first area of a dual zone, you should rotate the control knob between 1 – 11 and select the heat setting of your choice.
- o To activate the second area of a dual zone as well, you should rotate the knob past 11 and then turn it back to the heat setting of your choice.
- o To return to only one area operating, return the control knob to zero and then turn it back to your desired heat setting.
- o **IMPORTANT: When using a dual zone, it is important that the control knob is only turned clockwise.**

- o When you have finished cooking on a particular zone, it is important to make sure that the control knob is turned back to 0 (the off position).
- o A warning light on the control panel will inform you if a cooking area is turned on or off.

Hob guidelines

- o The first few times the hob top is used, it may give off an acrid, burning smell. This smell will disappear completely with repeated use.
- o The worktop is fitted with cooking areas of different diameter and power.
- o The positions where the heat will radiate from are clearly marked on the hob top. The saucepans must be positioned exactly on these zones for efficient heating to occur. Pans should have the same diameter as the cooking zone that they are being used on.
- o You should not use saucepans with rough bottoms, as this can scratch the ceramic surface.
- o Before use, make sure that the bottoms of the saucepans are clean and dry.
- o When cold, the bottom of the pans should be slightly concave, as they expand when hot and lie flat on the surface of the hob. This will allow the heat to transfer more easily.
- o The best thickness for the bottom of the pans is 2 – 3 mm of enameled steel and 4 – 6 mm for stainless steel with sandwich type bottoms.
- o If these rules are not followed, then there will be a great loss of heat and energy. Heat not absorbed by the saucepan, will spread to the hob, frame and surrounding cabinets.
- o Preferably cover pans with a lid to permit cooking at a lower heat.
- o Always cook vegetables and potatoes, etc. in as little water as possible to reduce cooking times.
- o For a faster heat up of a zone, you can turn the control knob to 11. Then when the contents of the saucepan are boiling, you may turn the control knob to a lower setting.

- o Food or liquid that has a high sugar content may damage the hob top if it comes into contact with the ceramic hob surface. Any spillages should be wiped up immediately, however this may not prevent the hob surface from becoming damaged.
- o **IMPORTANT:** The ceramic hob surface is tough; however it is not unbreakable and can be damaged. Especially if pointed or hard objects are allowed to fall on it with some force.
- o **DO NOT USE THE HOB IF THE SURFACE BECOMES BROKEN OR CRACKED. YOU SHOULD CONTACT THE BAUMATIC SERVICE DEPARTMENT IMMEDIATELY.**

Cleaning and maintenance



Cleaning operations must only be carried out when the oven is cool.

The appliance should be disconnected from your mains supply before commencing any cleaning process.

- o The oven should be thoroughly cleaned before it is operated for the first time and after each use. This will avoid residual food stuffs becoming baked on the oven cavity. After residues have been baked on several times, they are far more difficult to remove.
- o **Never** clean the oven surfaces by steam cleaning.
- o The oven cavity should only be cleaned with warm soapy water, using either a sponge or soft cloth. No abrasive cleaners should be used.
- o Any stains that may appear on the bottom of the oven will have originated from food splashes or spilt food, these splashes occur during the cooking process. These could possibly be a result of the food being cooked at an excessively high temperature or being placed in cookware that is too small.
- o You should select a cooking temperature and function that is appropriate for the food that you are cooking. You should also ensure that the food is placed in an adequately sized dish and that you use the drip tray where appropriate.
- o Outer parts of the oven should only be cleaned with warm soapy water, using either a sponge or soft cloth. No abrasive cleaners should be used.

- o If you use any form of oven cleaner on your appliance, then you must check with the manufacturer of the cleaner that it is suitable for use on your appliance.
- o **Any damage that is caused to the appliance by a cleaning product will not be fixed by Baumatic free of charge, even if the appliance is within the guarantee period.**

Cleaning the ceramic hob top



Any residues that are left on the hob top surface from cleaning agents **will** damage it. You should remove any residues with water and a little washing up liquid.



Abrasive cleaners or sharp objects will damage the hob surface; you should clean it using water and a little washing up liquid.



Although it is easier to clean some deposits whilst the hob surface is still warm. You should take care not to burn yourself if cleaning the hob surface when it is still warm.

After each use

- o Wipe the appliance over with a damp cloth and a little washing up liquid.
- o Dry the appliance by rubbing the surface with a clean cloth.


Cleaning table

Type of deposit	Remove immediately?	Remove when the appliance has cooled down?	What should I use to remove the deposit?
Sugar or food/liquid containing sugar	Yes	No	Ceramic hob scraper
Tin foil or plastic	Yes	No	Ceramic hob scraper
Fat splashes	No	Yes	Ceramic hob cleaner
Metallic discolourations	No	Yes	Ceramic hob cleaner
Water splashes or water rings	No	Yes	Ceramic hob cleaner

Using a ceramic hob scraper

It is possible to purchase a specialist ceramic hob scraper from supermarkets and/or hardware stores.

You should follow the instructions given by the manufacturer of the ceramic hob scraper. However following general guidelines should be followed when using the ceramic hob scraper:-



- o The scraper should be placed on the ceramic surface at an angle.
- o Residues should be removed by sliding the blade carefully over the ceramic surface.
- o The ceramic surface should be wiped with a damp cloth and a small amount of washing up liquid.
- o Dry the appliance by rubbing the surface with a clean cloth.

Using a specialist ceramic hob cleaner


It is possible to purchase specialist ceramic hob cleaner/conditioner.

You should follow the instructions given by the manufacturer of the specialist ceramic hob cleaner. You should ensure that it is suitable for use on your appliance.

Replacing the oven bulb




IMPORTANT: The oven must be disconnected from your mains supply before you attempt to either remove or replace the oven bulb.



- o Remove all oven shelves and the drip tray.
- o Unscrew the lamp cover.


- o Unscrew the bulb and remove it from its holder.
- o Replace the bulb with a 15 W/300°C, screw type pigmy.
- o **Do not** use any other type of bulb.
- o Screw the lamp cover back into its original position.

Removing the oven door for cleaning




- o Open the oven door fully.
- o The hinges **(A)** are provided with two movable hooks **(B)**.
- o Rotate the hooks into the slot **(C)**.
- o You should grip the sides of the door at the centre and then incline it slightly towards the oven cavity and then by pulling it gently away from the oven cavity.
- o **IMPORTANT:** You should make sure that the door is supported at all times and that you place the door on some padded material whilst cleaning it.
- o The oven door and door glass should only be cleaned using a damp cloth and a small amount of detergent. The cloth **MUST NOT** have come into contact with any form of cleaning product or chemical previously.
- o Replace the oven door by introducing the hinges back into their relevant slots. Before closing the doors **DO NOT FORGET TO RESET THE MOVABLE HOOKS.**
- o **DO NOT** attempt to move the hooks whilst the door is not attached to the oven, as the hinges are under high spring tension and injury may result.

Removing the inner door glass for cleaning



- o To facilitate cleaning, the inner door glass can be lifted out of the oven door.
- o Open the door halfway, you will see two screws on the top edge of the door. You should use a screwdriver to remove the screws and the strip that goes along the top of the oven door.
- o Using both hands pull the inner door glass out of the oven door.
- o **IMPORTANT: When the inner door glass is removed from the door, then the door springs will be under higher tension than normal. Therefore you should gently close the oven door, taking care not to trap your fingers.**
- o The oven door glass should only be cleaned with warm soapy water, using either a sponge or soft cloth. These should not have come into contact with any other chemical previously. Do not use any abrasive cleaner that could cause damage to the glass.
- o Remember that if the surface of the glass panel becomes scratched, this could lead to a dangerous failure.
- o When refitting, make sure that the glass is correctly seated in the door recess and the correct way round. You should slide the door glass back into its original position.
- o Using a screwdriver fully tighten the screws that attach the strip that you removed, to the top of the oven door.



- o **IMPORTANT:** Do not attempt to remove the door glass only using one hand.
- o **IMPORTANT:** Care must be taken when cleaning between the door glasses, and inside the inner frame as some of the edges maybe sharp due to the manufacturing process.

Installation



The installation must be carried out by a suitably qualified person, in accordance with the current version of the following.


- o **UK Regulations and Safety Standards or their European Norm Replacements.**
- o **Building Regulations** (issued by the Department of the Environment).
- o **Building Standards** (issued by the Scottish Development Department).
- o **IEE Wiring Regulations.**
- o **Electricity At Work Regulations.**
- o **Gas Safety (Installation and Use) (Amendment) Regulations.**

Positioning




The adjacent furniture and all materials used in the installation must be able to withstand a minimum temperature of 85°C above the ambient temperature of the room it is located in, whilst in use.

- o Your appliance is heavy, so you should be careful when moving or positioning it.
- o **Do not** try to move the cooker by pulling on either the door, handle or control panel.



- o The cooker is designed to slot in between 600 mm deep cabinets, which are spaced approximately 940 mm apart.
- o It can also be used as freestanding, with a cabinet to one side, in a corner setting or with its back to a wall.
- o **IMPORTANT:** It should not be installed at the end of a run of cabinets, if there is a cabinet at immediate right angles to the cooker door.
- o The wall behind the cooker and 450 mm above and across the width of the cooker should be an incombustible material and preferably an easy clean surface, such as ceramic tiles.
- o Any overhanging surface or cooker hood should be **at least 700 mm** above the highest point on the hob top (including the burners).
- o Baumatic do not recommend that the cooker is positioned below wall cupboards, as the heat and steam from the appliance and what is being cooked, may damage the cupboard and its contents.
- o The cooker may be located in a kitchen, or a bedroom, but not in a room containing a bath or shower. **The cooker must not be installed in a bedroom of less than 20m³ in size.**



- o The cooker is fitted with four legs that can be adjusted to match the height of your kitchen cabinets.
- o To assemble them it is necessary to raise the cooker and to screw the four legs into position, on each corner of the base of the appliance.
- o **IMPORTANT:** They must be screwed clockwise into position and not just slotted into the holes on each corner. You must screw them through the brackets that are also provided.

Electrical connection




This appliance must be installed by a qualified person in accordance with the latest edition of the I.E.E. Regulations and in compliance with Baumatic's instructions.

Before connecting the appliance, make sure that the supply voltage marked on the rating plate corresponds with your mains supply voltage.

WARNING: THIS APPLIANCE MUST BE EARTHED.

- o This appliance must be wired into a 32 A double pole switched fused spur outlet, having 3 mm contact separation and placed in an easily accessible position adjacent to the appliance. It should not be located above the appliance and no more than 1.25m away from it.
- o The spur outlet must still be accessible even when your oven is located in its operating position.
- o Cable type: H05 RRF 3 core x 6 mm²

Connecting the mains supply cable



IMPORTANT

The wires in the mains lead are coloured in accordance with the following code:

GREEN AND YELLOW
BLUE
BROWN

EARTH
NEUTRAL
LIVE

- o Open the mains terminal block cover as shown, unscrew the cable clamp (A) and unscrew (not fully) the screws in the mains terminal block (L, N, E) which secure the three wires of the mains cable.
- o Fit the cable and refit the cable clamp (A).
- o Allow sufficient cable length for the cooker to be pulled out for cleaning, but do not let it hang closer than 50mm to the floor.
- o The cable can be looped if necessary, but make sure that is not kinked or trapped when the cooker is in position.

Replacing the mains supply cable

If the mains supply cable is damaged, then it must be replaced by an appropriate replacement.

The mains supply cable should be replaced in accordance with the following instructions:

- o **Switch the appliance off at the control switch.**
- o Open the box of the supply board.
- o Unscrew the clamp (A) fixing the cable.
- o Replace the cable with one of the same length and in accordance with the specification given above.
- o The “green-yellow” earth wire must be connected to the terminal marked $\perp$. It must be about 10 mm longer than the live and neutral wires.
- o The “blue” neutral wire must be connected to the terminal marked with letter (N) - the live wire must be connected to the terminal marked with letter (L).

My appliance isn't working correctly

o The oven isn't coming on.

- * Check that the oven is in manual operation mode.
- * Check that you have selected a cooking function and a cooking temperature.

o There appears to be no power to the oven and grill.

- * Check that the appliance has been connected to the electrical mains supply correctly.
- * Check that the mains fuses are in working order.
- * Check that the operating instructions for setting the time of day and putting the appliance into manual operation mode have been followed.

o The grill function works but the main oven does not.

- * Check that you have selected the correct cooking function.

o The grill and top oven element is not working, or cuts out for long periods of time during use.

- * Allow the oven to cool for approximately 2 hours. Once cool, check whether the appliance is again working properly.

o My food is not cooking properly

- * Ensure that you are selecting the correct temperature and the correct cooking function for the food that you are cooking. It may be appropriate to adjust your cooking temperature by plus or minus 10°C, to achieve the best cooking results.

o My food is not cooking evenly

- * Check that the oven has been installed correctly and is level.
- * Check that the correct temperatures and shelf positions are being used.

o **The oven light is not working**

- * Refer to pages 27 - 28 and follow the "Replacing the oven bulb" section.

o **I am getting condensation in my oven**

- * Steam and condensation is a natural by product of cooking any food with high water content, such as frozen food, chicken etc.
- * You may get condensation in the oven cavity and forming between the oven door glasses. This is not necessarily a sign that the oven is not working correctly.
- * Do not leave food in the oven to cool after it has been cooked and the oven has been switched off.
- * Use a covered container, where practical, when cooking to reduce the amount of condensation that forms.



IMPORTANT: If your appliance appears not to be operating correctly, then you should disconnect it from your mains supply and then contact the Baumatic Service Department on telephone number (0118) 933 6911.

DO NOT ATTEMPT TO REPAIR THE APPLIANCE YOURSELF.

Please note that if an engineer is asked to attend whilst the product is under guarantee and finds that the problem is not the result of an appliance fault, then you may be liable for the cost of the call out charge.

The appliance must be accessible for the engineer to perform any necessary repair. If your appliance is installed in such a way that an engineer is concerned that damage will be caused to the appliance or your kitchen, then he will not complete a repair.

This includes situations where appliances have been tiled in, sealed in with sealant, have wooden obstructions placed in front of the appliance, like plinths. Or any installation other than the one specified by Baumatic Ltd. has been completed.

Please refer to the conditions of guarantee that appear on the warranty card that you receive with the appliance.

**United Kingdom**

Baumatic Ltd.,
Baumatic Buildings,
6 Bennet Road,
Reading, Berkshire
RG2 0QX
United Kingdom

Sales Telephone

(0118) 933 6900

Sales Fax

(0118) 931 0035

Service Telephone

(0118) 933 6911

Service Fax

(0118) 986 9124

Spares Telephone

(01235) 437244

Technical Advice Telephone

(0118) 933 6933

E-mail:

sales@baumatic.co.uk
technical@baumatic.co.uk

Website:

www.baumatic.co.uk

Republic of Ireland

01- 6266 798

Czech Republic

Baumatic CR spol s.r.o.
Amperova 495
46215, Librec
Czech Republic

+420 800 185 263

www.baumatic.cz

Slovak Republic

Baumatic Slovakia, s.r.o.
Skultetyho 1
831 04 Bratislava 3
Slovakia

+421 255 640 618

Germany

Baumatic Gmbh
Janderstrasse 9
Mannheim, 68199
Germany

+4962 112 9190

www.baumatic.de

Italy

Baumatic Italia S.R.L.
Via Caltana 129
Campodarsego (Padova), 35011
Italy

+3904 9920 2297

www.baumatic.it

Holland

Baumatic Benelux B.V.
Grindzuigerstraat 22
1333 MS ALMERE
The Netherlands

+3136 549 1555

www.baumatic.nl

