

AlertCam

Standalone combined PIR camera with RF transmitter



www.espuk.com

IMPORTANT

IF IN ANY DOUBT ABOUT THE INSTALLATION OF THIS PRODUCT, CONSULT A QUALIFIED ELECTRICIAN

- This product must be grounded
- Do not mount the unit against inflammable surfaces
- The motion detector will not operate correctly if it is installed:
 1. Near the outlet of a central heating boiler
 2. Near air conditioning
 3. Pointing directly at moving vehicles (may cause false triggering)
 4. Within sight of reflections from moving water (may cause false triggering)
- Where other lamps could shine on the detector

BEFORE ATTEMPTING ANY INSTALLATION OR MAINTENANCE, ENSURE THAT THE ELECTRICAL SUPPLY IS SWITCHED OFF AND THE CIRCUIT FUSES REMOVED OR THE CIRCUIT BREAKER IS IN THE OFF POSITION.

Please make sure the voltage and polarity are correct before connection. Incorrect voltage may cause electric shock. If you are not sure, please contact your distributor.

Table of contents

Contents and Optional Extras	3
Step 1: Installing the AlertCam	4
Step 2: Insert/remove SD card	5
Step 3: Adjusting the Settings	6
Step 4: Set the Date and Time	8
Step 5: Viewing recorded or live footage via a PC	8
Step 6: Viewing video	10
Technical Specification	12

Contents



AlertCam



User Manual



Drivers Disk



1 x Allen key
2 x screws
2 x masonry plugs



2G SD card



USB Cable

Optional Extras



AlertCam RA
Remote chime alarm device




AlertCam RS
Remote 1500w switching device

Step 1: Installing the AlertCam

Note: It is recommend to mount AlertCam 2M above the ground for optimum performance, do not mount the fixture below 1.2M. See below figure for details of performance range.




Detection range: 10M x 160° (see Fig. 1)



Mounting and wiring the AlertCam

1. To remove the rear mounting plate release the screw at the rear underside of the unit and ease the mounting plate from its housing
2. Feed the required cables through the glands supplied.
3. If AlertCam is to be used without a local lighting unit please see wiring diagram Fig. 2.
4. If AlertCam is to be used to switch a local light unit (max 500w) please see wiring diagram Fig. 3.
5. Ensure all wires are connected securely and that no loose strands are exposed. Make sure the polarity is correct. Double-check the connections after wiring. Errors may damage the motion sensor or cause a fire hazard.
6. Please allow 1-minute warm-up time after switching on.


* Push the RESET button after switching on.



Important note:
Please remove the plastic lens cover from camera after installation.

Step 2: Insert/remove SD card

- Unscrew the waterproofed cover using provided Allen key, then insert the SD card until it automatically locks into place.
- If you need to remove the SD card, please press OFF button and take it out within 30 seconds.
- When LED light turns green, SD card is being read, do not remove SD card at this time or data may be lost.
- To remove SD card, push in SD card to eject.



Step 3: Adjusting the Settings

■ Aiming the AlertCam (see Figs. 6, 7 and 8)

Alertcam has built in low energy laser device that can be used to aim the camera at a the optimal viewing area.

This operation is best carried out in dull light conditions. Please be aware that although the laser is very low energy you should avoid directly looking into the source as eye damage may occur.




Fig. 6

1. To activate the laser press pads at either side of the AlertCam.
2. The laser spot is the center position of the camera angle position.




Fig. 7




Fig. 8

- **Time control:** Turn the time control knob to "+" side to increase the illumination time (7 minutes max.), turn the control knob to "-" side to reduce the illumination time (30 seconds min.).
- **Lux control:** The lux control is used to set the required ambient light required to activate the light switching capability of AlertCam. Please note the Lux control does not effect the operation of the PIR detector , Camera and RF transmitter which operate in all light levels.

■ **LED indicator:** The function status of AlertCam is indicated by the following led colours.

- 1) Red: SD card is not inserted into the SD slot or system is malfunctioning or USB is inserted and connected with a computer.
- 2) Green: The unit is recording
- 3) Red Flash: The recorded files are deleting.
- 4) LED off: stand by mode when off/record button is pressed

Please note: when off/record button is pressed it is possible to safely remove the SD card within 30 seconds. After removal the LED will be red to show SD card is not present.

■ **Reset button:** restore functions to default settings

- 1) Press RESET button once each time you turn on unit.
- 2) Please press this button in case of system malfunction.

■ **Off/Rec:** Please press Off/Rec button to remove SD card. Please remove card within 30 seconds of pressing the Off/Rec button to avoid loss of data.

■ **RF Switch Code:** The AlertCam has a built in RF transmitter (approx 60m open field range) that can send wireless trigger signals to the optional AlertCam RA (remote alarm unit) or AlertCam RS (remote switching unit). The AlertCam will only activate remote units with matching RF codes. All AlertCams and remote units are factory set with the same RF code however codes can be easily changed to avoid false triggering of adjacent units. Remove the white plastic cover of the RF switch and set the switches to either on or off. To sync a receiver set it's four dip switches to match that of the AlertCam.





Fig. 9

Step 4: Set the Date and Time

This will allow the security video taken by AlertCam to display the correct date and time it was taken.

Push TIME/DATE SET button (see Fig. 10) for 3 seconds, the LCD screen will then flash 3 times, indicating you have entered Time/Date setting mode.

1. "YEAR" setting: "Y" and "08" are displayed on the screen; push the button to set year from "08-99", push the button again and hold for 3 seconds to scroll through numbers quickly. If you have not pressed the button for 3 seconds, it will automatically save the year and go on to allow you to set the month.
2. Repeat the same setting procedure for MONTH/DATE/HOUR/MINUTE.



Step 5: Viewing recorded or live footage via a PC or laptop

The PC will first need to have installed the bespoke drivers contained on the enclosed CD.

To run correctly the minimum requirements of the PC should be as follows:

- Windows 98/98SE/2000/ME/XP/Vista/WIN 7 (sorry, not MAC)
- Pentium III 450MHz or higher.
- 128MB RAM or higher.
- Display Card with 32MB RAM or higher.
- CD-ROM driver and USB Port.
- 2.5GB free hard disk space.


Installing the viewing drivers


- Insert the provided CD-ROM
- Locate the files on your PC
- Chose "IP298X USB CAMERA"
- Follow the instructions on the installation screens
- If you computer doesn't run the installation program automatically, please click the "Start" button and choose "Run." Then browse your computer to find the file name under which you saved the driver and click " Setup."
- Three files will appear after installation:
 1. Amcap RTC: Live image
 2. SDR View: Play the video
 3. Uninstall: Remove the software

Step 6: Viewing video

AlertCam records images to the SD card at 2 frames per second in sections of 20secs (ie a 40 frame sequence). The SDR software included will allow the frames to be viewed as a continuous video clip.



1. Viewing image by computer through a card reader (see Fig. 11 and 12)
 - Open the waterproofed cover from bottom of AlertCam (Fig. 11)
 - Press OFF/REC button and remove SD card (part no. 2) from the slot.
 - Put the SD card (part no. 2) into a card reader, connect PC and card reader and open SDR View. Click "m" button to choose which recording file you want to see the video then click "f" or "g" button to forward or backward playing the video. (Fig. 12)





Viewing direct live video during installation

It is possible to view live images directly from the AlertCam to a laptop during installation to ensure the camera is aligned correctly using the enclosed AmCap RTC software. Connection must be made using a mini USB - USB cable (See Fig. 9 & 13).



Technical Specification

PIR detection range	10m
PIR detection angle	160 Deg (adjustable)
Camera viewing angle	60 deg
Camera resolution	640x480
Max direct load	500W (50W LED)
Camera controls	Automatic white balance and exposure
Recording medium	SD (FAT16) or SDHC (FAT32) Max 64GB
Record rate	2 FPS for 20secs per trigger
Recording capacity with supplied 2GB SD	1,000 files of 40 images
Image format	JPEG (converts to video stream via bespoke software)
USB interface	Micro B type USB2
RF Trigger range	Up to 50M - Clear line of sight
IP Rating	IP55
Dimensions	108(D) x73(W) x138(H)mm

Technical Support 01527 515145

Elite Security Products
Unit 7, Target Park, Shawbank Rd
Lakeside, Redditch B98 8YN



Telephone: 01527 515150
Technical Support: 01527 515145
email: info@espuk.com

www.espuk.com