DT8012F4 / DT8012F5 DUAL TEC® Motion Sensor - Installation Instructions

QUICK LINKS

Mounting Location Guidelines


Open the Sensor

Mount the Sensor

Sensor Components and Settings

Wire the Sensor Walk Test the Sensor Detection Patterns Relay Operation

Troubleshooting
Sensor Specifications
Accessories
Approval Listings




- The optimal range is obtained at a mounting height of 2.3 m (7' 6").
- Allow a clear line-of-sight to all areas to protect.
- · Do not directly face windows.
- · Avoid close proximity to moving machinery, fluorescent lights and heating/cooling sources.
- For use in applications with pets up to 45 kilograms (100 pounds).




[EN] = approved installation.


2 OPEN THE SENSOR




- 1. Turn the arrow to point to the Unlock symbol.
- 2. Press firmly on housing latch.
- 3. Gently separate the front and rear housing.












6

WALK TEST THE SENSOR AND ADJUST AS NEEDED.





LED	Power Up	Walk Test	Normal	Trouble
Red	Slow Blink	ON Alarm	ON Alarm	Fast Blink
Yellow	OFF	ON Microwave	ON Microwave	OFF
Green	OFF	ON PIR	ON PIR	OFF

- 1. Close the sensor and apply power to the sensor. Initialization is complete when the LED stops flashing slowly (about 30 seconds).
- 2. Walk through the detection area and observe the LED.
- 3. Adjust the microwave range as necessary to meet installation requirements.


Walk test mode is active for 10 minutes, then automatically exits test mode, disables the LED and enters normal operation mode. For an additional 10 minute walk test, enable walk test mode again with the flashlight feature:

Note: During power up and walk test modes the LED is active regardless of the LED Enable/Disable DIP switch setting.

Flashlight Feature:

- 1. Use a flashlight with a bright light beam, and stand within 1.2 m (4') of the sensor.
- 2. Swing the light beam past the sensor lens 3-5 times, holding the beam on the lens for 0.5 second each pass.

The flashlight feature is only available for the first 24 hours after the first power up.




A


DETECTION PATTERNS

Top View

PLAN VIEW ALL ZONES



Side View



Zones

Α	2 Look-down	
В	18 Lower	
С	46 Intermediate	
D	36 Long	



RELAY OPERATION

	SENSOR STATUS		
	Normal	Intrusion	Trouble ¹
Alarm Relay	Closed	Open	Open

¹ For information on Trouble conditions, see the Troubleshooting section.

TROUBLESHOOTING



		TROUBLE*	
	NORMAL	Self-Test Failure ¹	
Alarm Relay	Closed	Open	
Red LED	Off	Flashing	

*TROUBLE CONDITIONS:

- ¹ Self-Test Failure conditions:
- · Microwave supervision failure: The sensor is operating in PIR mode only.
- · PIR self-test failure: The sensor is disabled.
- Temperature compensation failure: The temperature compensation is disabled.

Depending on the Trouble condition, take the following corrective actions:

- Verify the power supply is sufficient (at least 9V at the sensor).
- · Cycle power to the sensor.
- Walk test the sensor.

If the Trouble condition does not clear, replace the sensor.

SPECIFICATIONS



Range: 12 m x 17 m

Power: 9.0 - 15 VDC; 9 mA typical, 14 mA maximum, 12 VDC;

AC Ripple: 3 V peak-to-peak at nominal 12 VDC

Alarm Relay: Energized Form A; 30 mA, 25 VDC, 22 Ohms resistance maximum. Alarm Relay Duration: 3 seconds

Tamper: Cover; (NC with cover installed) Form A; 30 mA, 25 VDC;

Magnetic field

Microwave Frequencies: DT8012F4 - 10.525 GHz

DT8012F5 - 10.587 GHz

RFI Immunity: 20V/m 10-1000MHz, 15V/m 1000-2700MHz

PIR White Light Immunity: 10,000 Lux typical Fluorescent light filter: 50 Hz / 60 Hz.

Operating Temperature: -10° to 55° C / 14° to 131° F

Relative Humidity: 5 to 95%; non-condensing Temperature Compensation: Advanced Dual Slope Dimensions: 9.8 cm H x 5.7 cm W x 4.35 cm D /

4.57" H x 2.76" W x 1.69" D

Weight: 96 g / 3.38 oz (net weight)

ACCESSORIES*

SMB-10 (P/N 0-000-110-01)	Swivel Mount Bracket	
SMB-10C (P/N 0-000-111-01)	Swivel Mount Ceiling Bracket	
SMB-10T (P/N 0-000-155-01)	Swivel Mount Bracket w/Tamper	

^{*} Accessories are not covered by certifications.



APPROVAL LISTINGS





"[EN]" where noted in Steps 1-4).

EN50131-2-4:2008, Security Grade 2, Environmental Class II. Suitable for connection to an EN 60950 Class II Limited Power Source.

Note: In EN 50131-2-4 compliant installations, mount the sensor at 2.3m, disable look down, enable pet immunity, set the microwave sensitivity to maximum and lock the sensor housing with the cover lock (see

IMPORTANT: The sensor should be tested at least once each year.



NF&A2P 2 boucliers (référentiel NF324-H58) et conforme aux normes EN50131-2-4 et RTC50131-2-4; IP30 IK04

DT8012F4 – N° de certificat: 2821420019 DT8012F5 – N° de certificat: 2821420019

Organisme de certification: CNPP Cert.: www.cnpp.com et AFNOR Cert.: www.marque-nf.com

Honeywell Security Group - BP1219 1198 avenue du docteur Maurice Donat Sophia Antipolis 06254 Mougins Cedex.

TEL: +33.4.92.94.29.50 FAX: +33.4.92.94.29.60



DT8012F4INCERT B-893-0014

DT8012F5 PD6662:2010

For any additional information, please refer to our Website: http://www.honeywell.com/security/emea/hscdownload

Or contact:

Honeywell Security Group Newhouse Industrial Estate Motherwell Lanarkshire ML1 5SB

narkshire ML1 5SB Tel: +44(0)1698 738200

United Kingdom Email: UK64Sales@Honeywell.com

X

Please contact your local authorised Honeywell representative for product warranty information

