

Knightsbridge

These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.

Supplied By:
 (UK) Manufacturer: ML Accessories Ltd, Unit E, Chiltern Park, Boscombe Road, Dunstable, LUS 4LT, www.mlaccessories.co.uk
 (EU) SILV Lighting Group, Daimlerstraße 21-23, 52535 Libach-Palmborg, Germany
 Email: core@silv.com
 Made in China

SAFETY

- This product must be installed in accordance with the latest edition of the IEE Wiring Regulations (BS7671) and current Building Regulations. If in any doubt, consult a qualified electrician.
- Please isolate mains prior to installation or maintenance.
- Check the total load on the circuit including when this product is fitted does not exceed the rating of the circuit cable, fuse or circuit breaker.
- Do not overload this accessory or subject it to conditions outside its rating.
- Please note the IP (Degree Protection) rating of this product when deciding the location for installation.
- This product is for indoor use only.

INSTALLATION

- Connect the accessory as per the diagram in this manual, ensuring the correct polarity is observed (terminal positions may vary).
- L - LIVE - Brown
- N - NEUTRAL - Blue
- EARTH - Green and yellow
- All earth connections must be made and maintained. Use green/yellow sleeving on earth conductors that are not insulated.
- Check all electrical connections are secure with all exposed copper within the terminal and no loose or frayed conductors.
- Fit the unit into a suitable wall box taking care not to compress, damage or trap any cables, and secure with the screws provided. If using metal mounting boxes with four legs, remove the top and bottom legs or bend fully back.

FLAT PLATE, SCREWLESS AND RACKED RIDGE FIXING

- Always ensure the wall surface is flat and smooth.
- This unit is fitted with a gasket - this MUST NOT be removed, this gasket is to stop discoloration of the plate due to natural moisture in some wall finishes.
- This product must be fitted only after painting and decorating is complete.
- Schroto products only - remove the front plate by placing a medium size flat-head screwdriver in the notch at the side and lever off gently. After wiring and fitting to the wall box as per the instructions in this document, clip the front plate onto the main assembly ensuring the screwdriver notch is at the side.

METAL CLAD FIXING

- Remove front facplate and mount rear box in a suitable location. The back box has multiple 20mm cable entry points to aid installation.
- Wire as per the instructions in this document, and fix plate to back box using the screws provided.

OUTLETS WITH USB CHARGING FUNCTION

These products are designed for charging portable USB devices only, and contain a short circuit and overload protection feature. If there is no power from the USB socket supply the connected device. Check to ensure the USB socket and USB device have not come into contact with water, liquid or debris and the cable to the device is not damaged. With no device connected to the USB socket it will automatically reset and be ready for use.

WARNING !

This unit should NOT be subject to any insulation resistance testing, failure to follow this instruction could cause damage to the USB circuit and void the warranty.

GENERAL

This product should be recycled in the correct manner when it reaches the end of its life. Check local authorities for where facilities exist.

13A SOCKET WITH USB CHARGER

Clean with a soft dry cloth only, do not use aggressive cleaning products or solvents which may damage the product and invalidate the warranty.

13A SWITCHED SOCKET

13A SOCKET WITH QUAD USB CHARGER / QUAD USB CHARGER

13A SOCKET WITH USB AND BLUETOOTH SPEAKER / STAND ALONE BLUETOOTH SPEAKER

DUAL VOLTAGE SHAVER SOCKET

1A UNSWITCHED ROUND PIN SOCKET

BLUETOOTH AUDIO SPECIFICATION

- Output Power: Max. 3W RMS
- Sensitivity: 1.0V 380mV
- SNR: -85dB
- Speaker Frequency Range: 200Hz - 16kHz

BLUETOOTH CONNECTION

- Press the power button directly under the speaker.
- Bluetooth indicator will begin to flash.
- Activate Bluetooth pairing on your mobile device and scan for Bluetooth devices.
- Connect to the device named: **SPEAKER, SPEAKER1, SPEAKER2**, etc.
- Once a connection has been established you will hear a "beep" sound and the Bluetooth indicator will flash at a different frequency to confirm.

CHARGING INDICATOR

Products with LED charge indicators will change colour depending on the level of current drawn by the connected device. The Red/Green status indicator gives an approximate charge reading - please refer to device battery level for true reading.

ML Accessories Limited Unit E, Chiltern Park, Boscombe Road, Dunstable, LUS 4LT www.mlaccessories.co.uk

2-WAY SWITCH

Terminal positions may alter

2-WAY SWITCH **2-WAY SWITCH**

2-WAY INTERMEDIATE SWITCH

Terminal positions may alter

2-WAY SWITCH **INTERMEDIATE SWITCH** **2-WAY SWITCH**

2-WAY FAN ISOLATOR

DIMMER

DIMMER SWITCHES

- For a multiple gang dimmer repeat the wiring method for each dimmer unit.
- Two-way switching with a dimmer can only be achieved when there is only one dimmer in the system. Two-way dimming cannot be achieved.
- Please check with LED lamp manufacturer for compatibility.
- Ensure a mixed load is not selected, i.e. incandescent mixed with LED. Consider the minimum and maximum range of the dimmer according to the type of load installed.
- A small audible buzz may be emitted when using certain products. This is normal.

DIMMING ADJUSTMENT

If flicker can be seen in the dimming range at the lowest point, this can be eliminated by adjusting the potentiometer dial on the back of the unit (see Fig. X).

To adjust the potentiometer dial, isolate the power and rotate the dimmer switch to its minimum position. With the aid of a small flat-head screwdriver, rotate the potentiometer to adjust the low end of the dimming range. Switch on and check for correct operation.

Note - The dial has a stop position. Rotating past the stop position will not achieve further adjustment and may damage the unit.

2-WAY DIMMER

13A FUSED SPUR

20A SWITCH

4SA SWITCHES

COOKER CONTROL UNIT

These products have no cable entry and should only be used for "hard wired" installations.