

1) Fix the ceiling bracket to the ceiling in the desired location



2) Locate the installation holes on top of the motor



3) Lift the hood to the ceiling bracket. Ensure the holes on top of the motor correspond to the slider fixings on the bracket. Slide in to position



4) Secure with safety screws.

