## INF-PANIC

The INF-PANIC is a one-button hand-held transmitter designed for use with the infinite alarm system. This water-resistant transmitter is designed for panic-button applications and can be worn around the neck. Its large button makes it ideal for the elderly, disabled or sight-impaired users.

## Registration

- 1. Set the receiver to Registration mode.
- 2. Press the button, making sure that the LED lights up when the button is pressed.
- 3. Wait for five seconds and press the button again. Alternatively, the INF-PANIC can be registered to the receiver by manually entering the transmitter's serial number.

## Low Battery Indication

The INF-PANIC indicates a low battery condition using one of the following two methods:

- The LED indicator flashes during transmission.
- A Low Battery signal is sent to the receiver.

On receiving either of these indications, replace the unit.

## **Technical Specifications**

Antenna: Built-in whip

Frequency: 433.92MHz, 418MHz or 868.35MHz FM

RFI Immunity: 40V/m

Operating Temperature: 0 - 60°C Dimensions: 60 x 40 x 15mm




Figure 1: INF-PANIC (cord attached)



ESP- Electronics Line UK

Unit 7, Leviss Trading Estate, Station Road, Stechford, Birmingham B33 9AE.

IF YOU REQUIRE FURTHER ASSISTANCE PLEASE CALL OUR HELPLINE 0121 786 1881, SEND A FAX 0121 789 8055

Tel: (44-121) 789-8111, Fax: (44-121) 789-8055 OR AN EMAIL VIA OUR WEBSITE www.espuk.com



