

EARLEX[®]
SUPER STEAMER
STEAM WALLPAPER STRIPPER
OPERATING INSTRUCTIONS



MODEL SS100

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE USE

Thank you for purchasing an Earlex Steam Wallpaper Stripper. This is a highly versatile machine for use all around the home. In order to obtain the best results please read the instructions before commencing any work.

Please also make a special note of the safety rules and

RETAIN FOR FUTURE REFERENCE

SAFETY RULES

- Keep equipment away from children and pets.
- Ensure boiler is placed on a flat level surface, and should the boiler become tilted in use - level again immediately.
Failure to do so can result in severe overheating, complete element failure and void of your guarantee.
- Block boiler unit securely if using on stairs.
- The boiler becomes hot in use. Move only by using the carrying handle.
- Steam is produced at 100°C. Be careful, wear protective clothing and protect your hands with heat resistant gloves or mitts.
- Never point hose or steam plate at anyone.
- Always keep steam plate tilted away from face and body, beware of hot drips and regularly empty collected condensation from plate - especially when stripping ceilings and high areas.
- Never remove filler cap or detach hose whilst unit is operating.
- Never block the safety valve.
- Switch off and wait for 2 minutes before removing filler cap to refill boiler.
- Do not overfill.
- Allow to cool completely before emptying boiler.
- Do not stand on boiler or hose.
- Do not drag or try to move boiler by pulling the mains lead.
- Do not allow water or steam to enter light switches or power points.
- Do not leave unattended.
- Use only standard tap water. Never add detergents or chemicals.
- Extreme care must be taken if the unit is used in bathrooms. Always be aware of danger of electrocution from stored water in baths and sinks.
- Never change tools when the unit is operating.
- Always store upright.
- Do not overfill the reservoir.
- It is recommended that a RCD (residual current device) rated at 30mA is fitted into the mains supply socket for added protection against electric shock.

CAUTION !

Check the state of your plaster before starting work.

Steam can loosen weak, porous or poorly bonded plaster - which also loosens readily if cracked, holed or if the steam plate is held in one position for too long after the paper is soaked.

Weak plaster can normally be detected by tapping a few areas of wall. A hollow sound indicates that you should proceed only with extreme care - stopping immediately if you hear a cracking sound or plaster starts to break loose.


The steam stripper is safe for drywall/plaster board surfaces but whatever the material, it is always wise to check a small area before starting work properly.

PREPARATION

To achieve fastest paper removal always gently score the areas to be stripped.


With heavily embossed, vinyl coated or painted papers this is essential. Either use a proprietary perforator tool or alternatively score the paper with the edge of a wall scraper in a criss-cross pattern with 150mm (6 inch) spacing.

As with all decorating work be sure to protect carpets and furniture with covers.



FITTING CORNER BUMPERS AND CASTORS

A pack of 4 plastic corner pieces and 4 castors is enclosed to protect the unit. To fit the corner pieces simply push these over the aluminium edges at each corner and press home. To fit the castors turn the boiler upside down and push the castors in hard until they stop. Once installed these remain in place permanently.



OPERATION

STEAM IS HOT! The unit is designed for safe, fast removal of wallpaper but please be aware that steam is produced at 100°C - so be careful, wear protective clothing and protect your hands with heat resistant gloves or mitts.

FILLING:

Remove filler cap and fill unit to Max. level line or indicator with clean - preferably hot - water. Replace filler cap.

The capacity of 4.5 litres (8 pints) provides approx. 70 mins. steaming time before the safety cut-out operates.

For a shorter steaming time use less water. **Do not overfill the unit or hot water will be forced up the steam hose.**

Screw hose onto threaded outlets of boiler and steam plate, hand tight is sufficient. **Do not over tighten** but do check for hand tight fit from time to time during use.

Connect mains lead from unit to power socket and switch on. It can take up to 15 mins (approx.) before steam is produced - depending on fill water quantity and temperature.

Do not leave unattended and keep children & pets out of the room.

Just before full steam production a small amount of bubbling and water will occur at the steam plate.

Beware of hot water discharge prior to steam emission.

STRIPPING: Remember to check a small area first.

Operation is simple for both right and left handed people.

Simply hold the steam plate flat against the wallpaper for approx. 10 seconds. Now move the plate to the spot immediately next to the one just steamed - from which the paper should now easily come away with a little help from a wall scraper.

Working this way should enable continuous paper removal although it may be necessary to steam for longer periods with some papers, or if not completely removed first time.

Operate steamer until water level is low, then unplug unit and allow to cool for at least 2 minutes before removing filler cap - **Beware of steam** - and re-filling unit.

When finished, allow to cool completely and empty unit. Always store unit empty.



SAFETY CUT-OUT

A safety cut-out is fitted to prevent overheating the element if the water boils low. If unit stops boiling during use this may be the cause. Wait for 2 minutes before removing filler cap then re-fill with water. The cut-out will self reset and steam be produced again within 5-15 minutes.

The cut-out will not protect the element if a part filled unit is tilted during use in a way which enables part of the element to be out of the water for longer than 15-20 seconds.

OTHER USES FOR THE STEAM PLATE

Artex®

Normally Artex® can be removed using the same method as for wallpaper although the steaming time will be longer. CAUTION: Some textured finishes may contain asbestos which may be hazardous to health and which are subject to licensing controls operated by the HSE (Health & Safety Executive).

Vinyl Floor Tiles

Vinyl floor tiles can also be removed if the plate is left long enough for the heat to penetrate the adhesive. Once the adhesive is hot it softens and the tile can be peeled from the floor.

Sterilising Soil

To sterilise soil in seed trays or greenhouses rake the soil to obtain a fine surface. Leave the steam plate on each section, for 2 to 2.5 minutes which should ensure that the steam has penetrated through the surface.

Killing Weeds

Steam will kill weeds on paths and patios without the use of chemicals. You will need to steam the weeds for 1 to 1.5 minutes in order to kill them.



TROUBLE SHOOTING

Unit Fails to Boil

The unit has probably not been left for long enough to cool- refer to section on safety cut-out. Check the fuse in the plug is sound and is rated at 13 amps.

If using an extension lead check that it is rated at a minimum of 10 amps and fully unwound.

Unit Leaks Steam from Pressure Relief Valve

The pressure relief valve is a special low pressure valve and cannot be replaced by any other valve. If steam is leaking from the valve, the most likely cause is a blockage in the hose. Allow the hose to cool then remove the hose and check for any blockage. Always check the inlet in the tool you are using.

UNDER NO CIRCUMSTANCES FORCE THE VALVE SHUT. THIS IS OPERATING FOR YOUR PROTECTION.

DESCALING

To maintain peak performance of the unit, particularly in areas of hard water, it may be necessary to descale the element in the unit. Proprietary kettle descaling products can be used in your unit - always follow the manufacturer's instructions.

IF YOU REQUIRE FURTHER ASSISTANCE PLEASE CONTACT OUR HELPLINE ON:

Tel: 01483 454666 Fax: 01483 454548 email:enquiries@earlex.co.uk

Opening Hours: Monday-Thursday 08.30-17.00 Friday 08.30-16.30

MAINS CONNECTION

Your unit has been supplied with a mains lead and a fitted plug. This is identified by the fuse holder in the base of the plug. Please read the following safety instructions before use.

1 If the fitted plug is cut off from the mains lead then the plug must be disposed of safely. NEVER under any circumstances insert such a plug into a 13 amp socket.

2 NEVER under any circumstances use the appliance or mains lead without the fuse cover fitted. This is the little cover fixed into the base of plug to hold the fuse in place.

3 If you lose the fuse cover then please contact any electrical dealer for a replacement or ring our helpline.

4 A replacement fuse must be rated at 13 amp. These must be manufactured and approved to BS1362.

5 IF IN ANY DOUBT PLEASE CONSULT AN ELECTRICIAN.

If you need to fit a plug to the mains lead, this should be fitted in accordance with the wiring instructions below, and will need to be used with a 13 amp fuse. If in doubt consult an electrician.


WARNING - THIS APPLIANCE MUST BE EARTHED. If you are using an extension lead it must be rated at a minimum of 10 amps and fully unwound. Do not operate with a lead rated at less than 10 amps as this will cause premature failure of the element which is not covered by the guarantee.

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured green and yellow must be connected to the terminal in the plug which is marked with the letter E or by the earth symbol, or coloured green or green and yellow.

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.



GUARANTEE

This product is guaranteed for a period of 12 months against faulty materials and workmanship.

Whilst every possible care is taken by Earlex to ensure that our products leave the factory in good working order, Earlex cannot under any circumstances accept liability for problems or damage caused by their subsequent use.

It is the responsibility of the user to ensure that surfaces to be treated, cleaned or stripped are suitable for steam.

This guarantee does not affect your statutory rights. This guarantee excludes the use for hire purposes.

In the event of a fault occurring please contact our helpline before returning the unit to our Service Department at the address below together with a copy of your purchase receipt. All repairs will be dealt with speedily.

EC Declaration of Conformity

We declare that the unit: SS100 conforms to: 73/23/EEC, EN60335-1, EN60335-2-15 & 89/338/EEC, EN55014, EN50082-1.

Tim Hopper-Technical Director

ADDITIONAL STEAM CLEANING ACCESSORIES

A range of accessories is available for use with the wallpaper stripper to adapt it for many other tasks around the home.

EA10 Upholstery Cleaner - For cleaning upholstery, painted walls, car interiors. Also a small steam plate for wallpaper stripping.

EA11 Carpet Cleaner - ideal for bringing your carpets up like new. No chemicals required.

EA12 Window/Tile Cleaner - Gets your windows sparkling clean. Cleans floor tiles and wall tiles.

EA13 Jet Nozzle - With scraper and brush for cleaning cookers, lawnmowers etc. Defrosts freezers. Gets rid of unsightly black growth on grouting.

EA14 Cleaning Bonnets - Pack of 3 cleaning bonnets for use with the Upholstery Cleaner

EA15 Sink Unblocka - For fast unblocking of U-traps in sinks, baths, washing machine outlets etc.

EA18 - Pack of 3 bonnets for Carpet Cleaner.

EA20 - Complete set of 3 Accessories - EA11, 12 & 13.

OTHER PRODUCTS FROM EARLEX.

PR9 Autofeed® Cordless Painting System - Portable battery operated paint rolling system. It has a 3 litre paint reservoir and 23cm (9") roller and automatically feeds paint to the roller head. Easy to use the PR9 provides enough capacity for one coat of a 3.6m x 2.7m (12" x 9") room without having to refill.

PRA1 1.4mtr extension pole - Used in conjunction with the PR9 the PRA1 allows you to paint ceilings and high areas without the use of step ladders or having to move furniture.

WD1000 - Combivac Wet 'n' Dry Vacuum & Blower. The 1000W motor provides a powerful suction and blowing facility which is ideal for use around the workshop, garage, caravan, car,

garden and home. The 20 litre recovery tank has 12 litres wet capacity and is designed for the rough and tumble of every day use. The Combivac has on board storage facilities for its accessories, 6 metres of working length and a two year guarantee. There is also a variety of additional accessories available for use with the Combivac.

HG1600K - Heat Gun Kit. The Earlex Heat Gun Kit offers a 1600 Watt heat gun in a strong carry case and includes a range of useful accessories. With two heat settings the heat gun can be set at 400°C or 590°C. It is provided with a selection of four nozzles, three shavehooks and a scraper to suit different tasks and it all stores away conveniently in the carry case.

SG45 Super Sprayer® - 45W Electric Airless Spray Gun, ideal for spraying wood preservatives, varnishes, water & solvent based paints, enamels, varnishes and wood stains.

SG75 - Super Sprayer 75. 85W electric airless spray gun. The motor size and larger, additional nozzle (0.8mm) allows thicker viscosity liquids such as emulsions, latex, lacquers and impregnated agents to be sprayed. Includes a flexible extension nozzle that is ideal for spraying overhead and at different angles. Supplied with 2 nozzle sizes and a spares kit.

SG85 - Super Sprayer 85. 85W electric airless spray gun. The SG85 is a heavy duty spray gun designed for the semi-professional/tradesman with a tungsten carbide piston and a die cast aluminium head. These allow the product to deal with abrasive materials such as exterior wall paint (non-grit), latex, pottery glazes and similar materials that may be sprayed. Includes a flexible extension nozzle that is ideal for spraying overhead and at different angles, and a suction tube/cup attachment that clips onto the paint can, so that there is no need to keep refilling the paint container. Supplied with 2 nozzle sizes and a spares kit.



Earlex Ltd., Earlex House, Moorfield Road, Styfield Industrial Estate, Guildford, Surrey, GU1 1RU.
Tel: +44 (0) 1483 454666. Fax: +44 (0) 1483 454548.
email: enquiries@earlex.co.uk