




# DL/M/EMERGENCY PACK

## INSTRUCTIONS



# DL/M/EMERGENCY PACK INSTRUCTIONS



## EMERGENCY PACK COMMISSIONING.

1. Install unit in ceiling according to the instructions.
2. Provide an uninterrupted power supply for 48 hours.
3. Remove the mains supply – the lamp will operate under battery power
  - a. Battery discharge will last for 3 hours.
  - b. Restore mains power to the unit, check light functions correctly.
4. Repeat step 3 after a 24 hour period.
5. After 7 days, a 2 minute functionality test will be automatically carried out to check that the correct current is supplied from the battery.
6. Step 5 is repeated every 7 days for 1 year then a full test is carried out automatically, this checks both lamp operation and battery capacity.

## NOTE.

- a. If there are any problems, the indicator LED will flash.
- b. If there is an interruption to mains supply of more than 5 minutes the battery is automatically recharged for 48 hours.
- c. Tests will not be performed within 48 hours of a previous test or a mains failure exceeding 5 minutes.