




x1



x1



x1



x1



x2




x2



x2




x1














x1



x1








30mm





	Hello	Ding Dong	Westminster	Marimba	Piano	Bell	Telephone	Soft Alert
	•	•					•	•
	•	•	•	•			•	•
	•	•	•	•	•	•	•	•



		3Hrs 			6Hrs
		9Hrs 			12Hrs



GB Trouble shooting **DE** Fehlerbehebung **FR** Dépannage **NL** Probleemoplossing
F Vianmääritys **OK** Problemløsning **IT** Risoluzione dei problemi **ES** Solución de
 problemas **PT** Resolução de problemas **GR** Αντιμετώπιση προβλημάτων **SE** Felsökning

livewell.honeywell.com

