

INSTALLATION & MAINTENANCE MANUAL SPIKE5SS













GENERAL INSTRUCTIONS:

These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.


These instructions should be used to aid installation of the following product: $\ensuremath{\mathsf{SPIKE5SS}}$

SAFETY:

- Installation of this luminaire should only be carried out by a qualified electrician or competent person to the current IEE Wiring Regulations (BS7671)
- Before installation/maintenance, ensure that all mains supply to the luminaire is switched off and the circuit fuses are removed or switched off
- Check the total load on the circuit, including when this luminaire is fitted, does not exceed the rating of the circuit cable, fuse or circuit breaker
- Please note the IP (Ingress of Protection) rating of this luminaire when deciding the location for installation
- This product is Class I and requires an Earth
- Please recycle this unit
- This product is non dimmable

INSTALLATION:

- **Note** If this luminaire is being used in conjunction with external PIR or sensors, please confirm with the manufacturer of the sensor that they are compatible with LED luminaires
- Provide power to the required point of installation (refer to BS7671 for correct cabling methods), suitable IP rated junction boxes should be used where required
- For installation in soil with the spike, ensure that the ground is suitable and away from electrical cables, water or gas pipes
- The spike of the luminaire is required to be pushed fully into the ground (distance of 110mm), please see fig 1



- If installing outdoors ensure that this power source is via a RCD or a RCBO
- The power source connections should be local and accessible via a suitable IP rated enclosure
- Switch on power and test for correct operation

GENERAL:

- The LED lamps fitted in this product are non-replaceable. The unit should be recycled in the correct manner when it reaches the end of its life. Check local authorities for where facilities exist
- Clean with a soft dry cloth only, do not use aggressive cleaning products or solvents which may damage the luminaire

WARRANTY:

This product has a warranty of 2 years from date of purchase. Failure to install this product in accordance with the current edition of the IEE Wiring Regulations, improper use, or removal of the batch codes will invalidate the warranty. If this product should fail within its warranty period it should be returned to the place of purchase for a free of charge replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.