



INSTALLATION & MAINTENANCE MANUAL

OWALL1xxP / OWALL2xxP

GENERAL INSTRUCTIONS

These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.

These instructions should be used to aid installation of the following product range: OWALL1xxP / OWALL2xxP

SAFETY

- This product must be installed in accordance with the latest edition of the IEE Wiring Regulations (BS7671) and current Building Regulations. If in any doubt, consult a qualified electrician
- Please isolate mains prior to installation or maintenance
- Check the total load on the circuit (including when this luminaire is fitted) does not exceed the rating of the circuit cable, fuse or circuit breaker
- Please note the IP (Ingress Protection) rating of this product when deciding the location for installation
- This product is Class I and must be earthed
- This product is IP54 rated

INSTALLATION

Note - Round cable should be used for the mains supply. The use of flat cable will cause water ingress into the fitting

- Provide power to the required point of installation. Suitable IP rated junction boxes should be used where required
- Remove the baseplate from the luminaire by loosening the screws on either side of the base
- Using the baseplate as a template, mark the location for, and drill the fixing holes ensuring not to infringe with any gas/water pipes or electrical cables
- Feed the mains cable through the rubber grommet to retain IP rating
- Fix the baseplate using the screws and wall plugs provided (see Fig. 1)




Fig. 1

- Connect the luminaire to the mains supply ensuring the correct polarity is observed:
L - Live (brown) E - Earth (green/yellow) N - Neutral (blue)
- Align the luminaire with the baseplate and refasten the screws
- Insert suitable GU10 lamps
- Switch on and check for correct operation

Note – the photocell switches the light on when the light level drops below 10-30 lux, and off when the light level reaches 30-60 lux (these settings are not adjustable). It is sensitive to artificial light as well as natural daylight.

WARNING

This luminaire must be disconnected from the circuit if subjected to any high voltage or insulation resistance testing. Irreparable damage will occur if this instruction is not followed.

GENERAL

This product should be recycled in the correct manner when it reaches the end of its life.

Check local authorities for where suitable facilities exist.

Clean with a soft dry cloth only, do not use aggressive cleaning products or solvents which may damage the product.

This product is non-dimmable.

WARRANTY

This product has a warranty of 2 years from date of purchase. Failure to install this product in accordance with the current edition of the IEE Wiring Regulations (BS7671), improper use, or removal of the batch code will invalidate the warranty. If this product should fail within its warranty period, it should be returned to the place of purchase for a free of charge replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.

**INTERNATIONAL
CONTACT DETAILS**



**230V
50Hz**



IP54



ML
ACCESSORIES LTD



**UK
CA** **CE**



02

ML Accessories Limited LU5 4LT
www.mlaccessories.co.uk