

## LTEF200CW - 200W LED Slim ECO Floodlight

## 

Please read these instructions before commencing installation & retain them for future reference. Important information

It is recommended that floodlights are installed by a qualified electrician ensuring the installation complies to current IEE wiring regulations & local building control.

- These products are designed for connection to a 220-240V mains supply.
- Any broken or damaged parts should be replaced as soon as possible.
- We will not accept responsibility for any claims arising from a poor installation.

## **SPECIFICATIONS:**

• Voltage range: 220-240 V/AC

• Frequency: 50/60 Hz

• **Power**: 200W

Lumen Output: 20500lmColour Temperature: 4000K

• Protection against electric shock: Class I. Requires

earth connection

• Ingress Protection: IP65

 Quality/Corrosive rating: Suitable for commercial use and indoor/outdoor applications

• Material: Die cast Aluminium body with tempered glass

diffuser

• Ambient temperature range: -8°C to +45°C INSTALLATION INSTRUCTIONS:

Always switch off mains supply before servicing.

- Shut off Power. (Fig.1)
- Mount the bracket on the wall (Fig.2)
- Terminate loose ends of wire to an appropriate IP Rated junction box or similar, ensuring Live, Earth and Neutral polarities are observed. (Fig. 3)

Live - Brown/Red Neutral - Blue/Black Earth - Yellow/Green

- Connect the fitting to its bracket. (Fig.4)
- Turn On Power (Fig.5) and test the luminaire.

**WARNING:** Ensure all items and screws are secure and fitted correctly.

- This floodlight is not dimmable.
- Floodlights should not be connected in series.

## **DIMENSIONS(mm):**





