

LTG2CCT



GALAXY 2 LED

IP65 Round Bulkhead

CCT Changeable / Tri Wattage



These instructions should be read carefully and retained after installation for further reference and maintenance.


- Before installation, ensure that the mains supply to the luminaire is switched off and the circuit supply fuses are removed or circuit breaker turned off.

 It is recommended that a qualified electrician is consulted or used for the installation of this luminaire and
- installed to the current edition of the IEE wiring regulations.
- Check that the total load on the circuit, including this luminaire, does not exceed the rating of the circuit cable, fuse or circuit breaker.

RATINGS

- This luminaire is of Class II construction and it does not require an earth connection
- IP65 rated
- F marked, suitable for installation on normal flammable surfaces
 Working situation: -15°C to 40°C
- 220-240V AC rated
- CE Approved

DIMENSIONS:









Standard Wiring:

WIRING DIAGRAM:



When used with Quick Plug-in LTEM Emergency Pack:



Use the LED gear tray switch

to change the CCT temperature

CCT & POWER ADJUSTABLE:



Open the LED gear tray and use the driver DIP switch to change the power


- Input Voltage: 220-240V/AC
- Tri-Power Selectable: 25W/30W/35W
- Light Output: 25W 2600lm 30W - 3150lm 35W - 3600lm
- CCT Changeable (switch): 3000K/4000K/6500K


TECHNICAL SPECIFICATIONS:


- CRI > 80 IP Rating: IP65
- Protection Class: Class II
- Housing: PC Body & Diffuser
- Operating Temp.: -15^oC to +40^oC
- Dimensions: Diameter 430mm / depth 110mm Warranty: 5 years


INSTALLATION INSTRUCTIONS:


Switch off the mains supply before installation.













Make sure the mains power supply is switched off. Feed the supply cable into the luminaire, ensuring the entry point is smooth or fitted with a grommet.Connect the cable to the terminal block following the wiring instructions.




Re-fit the diffuser by placing it over the base and lock into position using the screw.




Emergency Pack (LTEM) and Microwave Sensor (LTMS) Installation Instructions


⚠ Switch off the mains supply before installation.


Emergency Pack (LTEM) Installation:







Microwave Sensor (LTMS) Installation:





Emergency Pack (LTEM) and Microwave Sensor (LTMS) Installation:





LTEM & LTMS PLUG & PLAY INSTALLATION INSTRUCTIONS

