






Quinetic Configuration Tool System

Reduce your time spent configuring batch devices

-  *No Internet required*
-  *Local storage*
-  *Customised firmware parameters*
-  *Significantly reduce configuration effort*



Configure devices quickly and in batches

Just configure our devices with your mobile phone! Open our Quinetic ConfigPro APP, say bye to traditional physical key pairings to further assist in the demands of large constructions.



Network-free local scene automation

Remote wireless configuration through the Quinetic ConfigPro APP and no internet required. Use it to realise scene control in your home or office!



Your reliable privacy and security

Cloud-free and network-free!

Your data is directly stored in local devices in your space.



Customised firmware parameters

Customise the power-on status, bridge mode, time-delay or dimming method with the APP.



Customised firmware parameters

- Customise the power-on status
- bridge mode
- time-delay
- dimming method

01. Turn on your phone's Bluetooth



02. Open the Quinetic ConfigPro APP and search devices in the space



Discover




Config



Signal




My






03. Configure device pairing information

04. Customise brightness and colour temperature




05


05. Customise firmware parameters




01. Power-on status setting




02. Bridge mode setting




04. Dimming method setting



03. Time-delay setting



06. Real-time monitoring of signal strength information



07. Save configuration information

