



SCREWLESS – 1G 13A switched socket with quad USB charger

These instructions should be read carefully and retained after installation for further reference and maintenance.

SAFETY

- This product must be installed in accordance with the latest edition of the IEE Wiring Regulations (BS7671) and current Building Regulations. If in any doubt, consult a qualified electrician.
- Before installation or maintenance, ensure that the mains supply is switched off and circuit fuses are removed or circuit breakers switched off
- Do not overload this accessory or subject it to conditions outside its rating
- Please recycle

PLATE FIXING

- Always ensure the wall surface is flat and smooth
- Remove the front plate by placing a medium size flat head screwdriver in the notch at the side and lever off gently. Fix the main unit to the back box using the fixing screws supplied.
- Clip the front plate back onto the main assembly, ensuring the screwdriver notch is at the side
- This unit is fitted with a gasket, this **MUST NOT** be removed, this gasket is to stop discolouration of the plate due to natural moisture in some wall finishes
- To maintain the finish of this product, periodically wipe over with a soft dry cloth only, do not use abrasive cleaning products

WARRANTY

This product has a warranty of 15 years from date of purchase. Failure to install this product in accordance with the current edition of the IEE Wiring regulations (BS7671), improper use or removal of the batch codes will invalidate the warranty. If this product should fail within its warranty period it should

INSTALLATION

1. Connect the accessory as per the relevant diagrams
2. All earth connection must be made and maintained. Use green/yellow sleeving on earth conductors that are not insulated
3. Fit the unit into a suitable wall box taking care not to compress, damage or trap any cables, and secure with the screws provided
4. Check all electrical connections are secure with no loose strands

WIRING

L – LIVE – Brown

N – NEUTRAL – Blue

 – **EARTH – Green and yellow**

All class I, 230V flat plate products must have an earth connection between the plate and the back box

***NOTE – These sockets should not be connected during an insulation resistance test or damage will occur.**

If your installation uses four lug metal mounting boxes, remove the top or bottom lugs or bend fully back

IF IN ANY DOUBT PLEASE CONSULT A QUALIFIED ELECTRICIAN


be returned to the place of purchase for a free of charge replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.

USB charger specification: 5V DC
Total combined output: Max. 5100mA

Caution

This socket designed for charging portable USB devices only

This socket contains a short circuit and overload protection feature. If there is no power from USB socket unplug the connected device. Check to ensure the USB socket and USB device has not come into contact with water, liquid or debris and the cable to the device is not damaged. With no device connected to the USB socket it will automatically reset and be ready for use.



Knightsbridge[®]
the mark of quality