



LIGHT SHOW

General

The light show consists of a number of loose lamp modules and a control unit. The lamps are music controlled. The electronic controller and the microphone are built in the controller. The set includes coloured 230V 60W reflector lamps.

Installation and use

The light show can be used free standing in the supplied configuration or in a random built shape. The modules are interlockable. The modules are separated by pushing the lock backwards and assembled by putting two pods side by side or by stacking them and pushing the lock from the rear side into the rail.

Connect the lamp modules by plugging the Euro plugs from the modules into the controller as follows:

Channel 1 - Connection 1 & 2

Channel 2 - Connection 3 & 4

Channel 3 - Connection 5 & 6

After having connected all modules you can plug the control unit into a mains outlet.

Operation

Switch the unit on. Set the sensitivity via the rotary buttons on the controller. The more the buttons are turned clockwise, the more the lamps are sensitive to the rhythm of the music or any other sound.

Warning

- Only use the light effect for its original purpose.
- Only connect the supplied lamp modules to the control unit.
- Use reflector lamps of 60W max. If you use more powerful lamps, they might overheat and cause fire.

- Do not use halogen or gas lamps.
- Do not replace the mains leads.
- Do not open the unit – risk of electrical shock.
- The unit does not contain any user replaceable parts. Repairs should only be carried out by a qualified technician.
- Unplug the unit from the mains prior to changing a lamp.
- The unit is for indoor use only. Keep away from humidity.

Specifications

Power	220-240Vac / 50Hz
Wattage of the lamp modules	Max. 60W
Wattage of the control unit	Max. 150W per channel
Lamp type	60W reflector lamp type R80
Lamp fitting	E27