

## Warranty



To receive after sales service, have the following ready when you contact our branches

1. Name of the product
2. Model number of the product
3. The area of problem
4. Phone number and address at which you can be contacted.

## Warranty Card

PRODUCT	
MODEL	
DATE PURCHASED	
WARRANTY PERIOD	
AGENCY	
AGENCY ADDRESS	

© KOCOM Warranties the original purchaser of this product as follows.

- 1) This product is produced under strict quality control and inspection procedures.
- 2) If this product breaks down during proper use as a result of product defect, KOCOM will repair it within one year from date of purchase free of charge.
- 3) The following cases will be subject to charge, even during warranty period:
  - a. Breakdown during transport, or through careless treatment, by consumer.
  - b. Breakdown caused by unauthorized repair, or system modification.
  - c. Breakdown caused by natural disaster or power disorder.

**KOCOM CO.,LTD.**

This manual is based on the date as shown in the right and specifications are subject to change without notice for quality improvement.

09.04


# KOCOM

# DIRECT INTERPHONE


KIP-60IPM / KIP-60IPS MANUAL FOR OPERATION AND INSTALLATION

## Features

- Perfect for private conversations
- Delightful sound
- Easy wiring with 2 lines of polarity
- Power : D.C 6V (main only) 4 Piece of 1.5V batteries (one side insert)
- Range: φ 0.65mm wire, 300m line
- Easily mounted on wall, desk








Thank you very much for purchasing KOCOM Interphone. please read this manual thoroughly to ensure correct usage, before operating




**CE**

**KOCOM CO.,LTD.**




### Precautions for Operation

 <p>As this device consists of precise electronic components, and high voltage is generated internally, do not attempt to disassemble.</p>	 <p>When cleaning, never use wet hands, volatile benzene or paint thinner.</p>
 <p>Do not drop indoor station, and avoid strong impact.</p>	 <p>Maintain the product clear by frequently cleaning with soft cloths</p>
 <p>Keep away from humidifier and stove. High temperature and humidity can cause malfunction</p>	


### Name of Each Part




### How to operate (Instruction for operating)

 <p>When a visitor pushes the main station bell,</p>	 <p>The sub station is ringing.</p>	 <p>Pick up the handset and communicate with a visitor. After end of communication, return the handset where it is locked</p>
---	--	--

### Wiring Diagram



### Installation



- A- Choose a place on the wall where you want to hang the indoor station.
- B- Fasten the wall hanger on the wall.
- C- Indoor station can be hung on the wall hanger easily now.

### Specifications

Description	KIP-601PM	KIP-601PS
Electric source	DC 6V	Power from Main (KIP-601PM)
Consumption	Un Load: 0.2mW, In Load: 1W	Un Load: 0.2mW, In Load: 1W
Signal Sound	Electronic Chime	Electronic Chime
Wiring	2Wired polarity	2Wired polarity
Range	300m(φ 0.65mm)	300m(φ 0.65mm)