

LightScene™ from Varilight®



Do you have more than one Eclique dimmer in your room?

Now you can access extended features with the LightScene™ infrared handset.

With LightScene™ you can record up to four lighting scenes and recall them with a touch of a button.



We've also added shortcut keys to added functions such as selecting full brightness, half brightness or minimum brightness as well as functions that turn all the lights on or off.

You can also use the LightScene™ handset to reset the minimum brightness level of the dimmer to optimise the dimming range of LED lamps.

LightScene™ Functionality Guide

	●		●		★
ON MAX		LIGHT 1	ALL UP		SAVE SCENE 1
OFF		LIGHT 2	ALL DOWN		SAVE SCENE 2
LAST SCENE		LIGHT 3			SAVE SCENE 3
SHIFT		LIGHT 4	SHIFT		SAVE SCENE 4
					RECALL SCENE 3
					RECALL SCENE 4