



Xpelair Wiring Diagrams

Xpelair Premier DX180 & DX180T/H

Premier DX180




Premier DX180T/H




Xpelair Premier DX200 & DX200T

Premier DX200




Premier DX200T




Xpelair Premier CF20 & CF20T

Premier CF20




Premier CF20T




Xpelair Premier LoVolt DX200 & LoVolt CF20


Premier LoVolt DX200T



Premier LoVolt CF20




Premier LoVolt CF20T




Xpelair DX100 & XX100

DX100/PC/HP/PIR/XX100/P




DX100T/H/XX100T




Xpelair LoVolt LV100

LV100/PC/H/HP/PIR




LV100T




Xpelair Slimline SL100, SL100P & SL100T/HT


Slimline SL100



Slimline SL100P




Slimline SL100T/HT




Xpelair CentrX

CentrX CT100/100+/100+P




CentrX CT100T/HT/100+HT




Xpelair XIL Inline shower fan systems

XIL100/125/150/XXS100




XIL100T/125T/150T/XXS100T




Xpelair Wiring Diagrams

Xpelair BriteX LoVolt & BriteX Turbo

BX100W/C/BX100+W/C




BX100WT/CT/BX100+WT/CT




Xpelair XIM


XIM100/100+/125




XIM100T



XIM150/200




XIM150T




Xpelair Slimline 150


Slimline SL150



Slimline SL150P




Slimline SL150HT




Xpelair GX6, GXC6 & GXC9

GX6




GXC6, GXC6T, GXC6SC & GXC9




Xpelair Premier DX400 & CF40


DX400




DX400PC



DX400T/CF40/CF40TD




DX400RS/CF40RSTD



Xpelair Wiring Diagrams


Xpelair Nouvelle Cuisine

Kitchen Canopies




Xpelair CX10 & CMF

CX10/CMF




Xpelair Xvent

Xvent275/340




Xvent275/340 with 3 speed switch




Xpelair Xcell 270 Longlife

Xcell 270




Xpelair Xcell 300 & 400 Longlife

Xcell 300/400




Xpelair EverDri LongLife

EverDri XEDW/XEDL




Xpelair LoVolt XHR150

XHR 150




Xpelair GX6, GX9 & GX12

GX6




GX9/GX12




Xpelair PX6, PX9 & PX12

PX6




PX9/PX12




Xpelair RX6, RX9 & RX12

RX6




RX9/RX12




Xpelair Wiring Diagrams

Xpelair WX6, WX9 & WX12


WX6



WX6T




WX9/WX12




Xpelair ChefX

ChefX Tempo/Presto/Mezzo




Xpelair WH30 & WHP30


WH30



WH30 with HC301




WHP30 with HC301




Xpelair WH60


WH60-single phase



WH60-3 phase using a 240V contactor coil




WH60-3 phase using a 415V contactor coil




Xpelair ScreenHeat & PlinthHeat

PlinthHeat with integral controls




PlinthHeat with remote control



Xpelair Whispair


NWAN




Xpelair Wiring Diagrams

Xpelair XPMS, XPMA & XRA


315/350/400




450




500/630




315/350/400 with XCW controller




450 with XCW controller



500/630 with XCW controller




Xpelair XSCS & XSCA




Xpelair XMV

Single phase




3 phase




Xpelair XID & XIDP

XID/XIDP




XID/XIDP with XIC1 speed controller



Xpelair LoSound XSFA

XSFA



Xpelair SuperBlowers

SB1

