

Electronic Modular Switching System

**Panasonic**

**U**ser  
**M**annual

Please Read this manual before using  
the Electronic Modular Switching  
System.

**For Single line telephones**

Model  
KX-T206E

# Single Line Telephone Features

---

## Contents

Making Calls .....	3
Intercom Calling.....	3
Outward Dialling.....	3
System Speed Dialling .....	3
Doorphone.....	3
When a Line is Busy.....	3
Last Number Redial.....	3
Receiving Calls .....	4
Answer .....	4
Call Pickup.....	4
While Having a Conversation .....	4
Call Hold .....	4
Call Hold Retrieve.....	4
Call Transfer.....	4
While Having a Conversation (contd.).....	5
Call Waiting .....	5
Conference.....	5
Call Splitting .....	5
Paging Features .....	6
Paging All Extensions .....	6
Paging Answer .....	6
Paging and transfer.....	6
Other Features .....	6
Intercom Alerting Mode.....	6
Other Features (contd.).....	7
Call forwarding.....	7
Call Pickup Deny.....	7
Do Not Disturb (DND).....	7
Other Features (contd.).....	8
Data Line Security.....	8
Pulse to tone conversion.....	8
Station Feature Clear.....	8
Other Features (contd.).....	9
Time Setting (extension 21 only).....	9
Date Setting (extension 21 only).....	9
Flexible Night Service.....	9

# Single Line Telephone Features


## Making Calls

<NOTE>

Off-Hook: Lift the handset    On-hook: Replace the handset

### Intercom Calling

Allows you to call another extension




The diagram shows a handset icon at the top left. Below it are two telephone icons. The first is labeled 'Off-hook'. The second is labeled 'Dial extension number (21 through 26)' and has a hand icon pointing to it.

### Doorphone

Allows you to have a conversation with a visitor at your door


*To call a doorphone:*



The diagram shows a handset icon at the top left. Below it are three elements: a telephone icon labeled 'Off-hook', the number '31', and a handset icon labeled 'Wait for confirmation and talk'. The number '31' is the largest element in the diagram.

### Outward Dialling

Allows you to make a call to an outside party



The diagram shows a handset icon at the top left. Below it are two telephone icons. The first is labeled 'Off-hook'. The second is labeled 'Dial line access code and telephone number' and has a hand icon pointing to it.

*To unlock the door:*




The diagram shows a handset icon at the top left. Below it are three elements: a telephone icon labeled 'Off-hook', the number '32', and another telephone icon labeled 'On-hook'. The number '32' is the largest element in the diagram.

### System Speed Dialling


Allows you to make outside calls using previously programmed speed dial numbers.

This system supports forty speed dial numbers which are available to all extension users

*To unlock the door while talking to the doorphone:*



The diagram shows a telephone icon at the top left. Below it are three elements: a telephone icon labeled 'Press RECALL', a hand icon pointing to it, and the number '3'. The number '3' is the largest element in the diagram. Below the number '3' is the text 'Dial 3'.



The diagram shows a handset icon at the top left. Below it are three elements: a telephone icon labeled 'Off-hook', an asterisk symbol labeled 'Press \*', and a telephone icon labeled 'Dial System Speed Dial number (00 through 39)' with a hand icon pointing to it.

### When a Line is Busy

#### Last Number Redial

Allows you to automatically re-dial the last outside number dialled.



The diagram shows a handset icon at the top left. Below it are two elements: a telephone icon labeled 'Off-hook' and the number '80'. The number '80' is the largest element in the diagram. Below the number '80' is the text 'Dial 80'.


# Single Line Telephone Features

## Receiving Calls

### Answer



### Call Pickup



## While Having a Conversation

### Call Hold

Allows you to place an intercom or outside call on hold.

*To place a call on hold:*




- Depending on the system programming you may need to dial 6 after pressing the recall button. For programming, see page 28 of the installation manual.

*To retrieve a call on hold:*



### Call Hold Retrieve

Allows you to receive a call that has been placed on hold by another extension.




- You can dial the extension number (21 through 26) which held the call or the line number.


### Call Transfer

Allows you to perform a screened or Unscreened call transfer to another extension.


*To perform a screened call transfer:*



*To perform an unscreened call transfer:*



*To retrieve the call when the transferred call is not answered within 30 seconds an the call has returned to you:*



- For programming the hold recall time, see page 28 of the Installation Manual.

# Single Line Telephone Features

## While Having a Conversation (contd.)


### Call Waiting

During a conversation, a call waiting tone signals that there is a call waiting. You can respond to the waiting call by disconnecting from the first call or by placing the first call on hold.

*To talk to the new party by terminating the current call:*




*To talk to the new party holding the current call:*



### Conference

Allows you to add a third party to a two-party conversation and make a three party conference. You can have the following combination of calls on the line: three extensions, two extensions and one line, or one extension and two lines.



*To leave the conference:*



On-hook


- The other two parties can continue their conversation provided they are not both lines.

*To hold one party and talk to the other:*



### Call Splitting

Allows you to have two callers on a line and alternate between them. You can place the current call on hold and have a conversation with the other party.



- Pressing RECALL alternates between the callers.
- When you go on-hook, the other two parties callers remain on-line.


# Single Line Telephone Features

## Paging Features

The Paging features allow you to make a voice announcement to several persons at the same time. Your message is announced over the built-in speaker of proprietary telephones. The paged person can answer your page from a nearby telephone.


### **Paging All Extensions**

Allows you to make a voice announcement to all extensions. Your message is announced over the built-in speaker of the proprietary telephones.




### **Paging Answer**

Allows you to answer an announcement page at any extension within the system.



### **Paging and transfer**


Allows you to transfer a call using the Paging to Extension feature.



## Other Features

### **Intercom Alerting Mode**

Allows you to switch voice calling to ring calling when making an intercom call. In Voice-Calling mode, you can talk to the other party immediately after the confirmation tone.



• For programming, see page 28 of the Installation Manual.


# Single Line Telephone Features

## Other Features (contd.)

### Call forwarding

You can redirect all of your calls to another extension.


*To set:*



Off-hook      Dial 7      Dial extension number  
(21 through 26)

Dial #      On-hook

*To cancel:*




Off-hook      Dial 70#      On-hook

- You may dial “0” instead of “#”

### Call Pickup Deny

Allows you to prevent another extension from picking up your calls with the “Call Pickup” feature.

*To set:*



Off-hook      Dial 731#      On-hook

*To cancel:*



Off-hook      Dial 730#      On-hook

- You may dial “0” instead of “#”

### Do Not Disturb (DND)

Allows you to prevent other parties from disturbing you. Your extension will not receive intercom or outside calls

*To set:*



Off-hook      Dial 720#      On-hook

*To cancel:*



Off-hook      Dial 70#      On-hook

- You may dial “0” instead of “#”.



# Single Line Telephone Features

## Other Features (contd.)

### **Time Setting (extension 21 only)**

Sets the correct time.

Off-hook      Dial 77      Enter hour  
(01 through 12)

Enter minute      Dial 0 (AM)  
or 1 (PM)      Dial #

- The clock starts immediately after pressing #.

### **Date Setting (extension 21 only)**

Sets the current date.

Off-hook      Dial 76      Enter year  
(2 digits)

Enter month      Enter day      Enter day of  
(01 through 12)      (01 through 31)      the week (1 (Sun.)  
through 7 (Sat.))

Dial #

### **Flexible Night Service**

(extension 21 only)

This system supports both DAY and NIGHT modes of operation. The system operation for originating and receiving calls can be different in night and day modes.

*To set the night mode:*

Off-hook      Dial 782#      On-hook

*To return to day mode:*

Off-hook      Dial 781#      On-hook

## Single Line Telephone Features

---

Feature	Number
Call Forward Set/Cancel	7 (extension number) # / 70#
Call Hold retrieve	5 (Line or Extension number)
Call Pickup	40
Call Pickup Deny Set/Cancel	731# / 730#
Conference	3
Data Line Security Set/Cancel	741# / 740#
Date Setting	76 Year Month Day Day-of-the-week #
Do Not Disturb Set/Cancel	720# / 70#
Doorphone Calling/Unlock /Unlock during conversation	31 / 32 3
Extension Calling	21 through 26
Flexible night service Set/Cancel	782# / 781#
Intercom Alerting Mode	*
Last Number Redial	80
Line access, Automatic	9 or 0 (depending upon system program)
Line access, Individual	81 or 82
Paging All Extensions	33
Paging Answer	43
Station Feature Clear	79#
System Speed Dialling	*00 through *79
Time setting	77 Hour Minute 0(AM)/1(PM) #32

**Note**

- you can enter “0” instead of “#” except with Date Setting, Flexible Night Service and Time Setting.

# Single Line Telephone Features

---

**Panasonic Business Systems U.K.**  
Panasonic House, Willoughby Road, Bracknell,  
Berkshire RG12 4FP

**Produced by Paul White**

KX-T206E/SLT