

# System Highlights

## System Capacity

<b>Basic System</b>	Extensions	8
	Exchange lines	3
<b>Expansion</b>	Maximum extensions	24
	Maximum exchange lines	6

## Special System Points

### System Expansion

This system can expand the exchange lines and extension capacity by installing an optional card.


☞ 2-24



### Calling from the outside (Direct Inward System Access)

External callers can call extensions in the system. If you install an optional card, an outgoing message will greet the caller and give information about how to access an extension.

☞ 3-22



### Hybrid

This system can accept Panasonic analogue proprietary telephones. Also, single line devices such as single line telephones, facsimiles and data terminals can be connected.

