



INSTALLATION & MAINTENANCE MANUAL

**TRKxxxx**


## GENERAL INSTRUCTIONS

**These instructions should be read carefully and retained after installation by the end-user for future reference and maintenance.**

**These instructions should be used to aid the installation of the TRKxx track products.**

## ACCESSORY INSTALLATION

- The track accessories are provided with earth connection points on both sides
- When offering the accessory to the track, verify which tab needs to be removed
- To remove the tab, grasp firmly with a pair of pliers and lever back. The tab should snap off cleanly. The side of the track with the earthing conductor has a polarity groove on top of the track to help identify which way round to insert the accessories (see Fig. 1)
- Locate the accessory into the track and insert fully



**Fig. 1**

- The track connectors TRKC1xx / TRKFC1xx / TRKRA1xx / TRKT1xx / TRKX1xx also have the two earth tabs and can be used as power feeds and rewired if required

## GENERAL

This product should be recycled in the correct manner when it reaches the end of its life. Check local authorities for where facilities exist.

Clean with a soft dry cloth only, do not use aggressive cleaning products or solvents which may damage the product.

## WARRANTY

This product has a warranty of 2 years from the date of purchase. Failure to install this product in accordance with the current edition of the IEE Wiring Regulations (BS7671), improper use, or removal of the batch code will invalidate the warranty. If this product should fail within its warranty period, it should be returned to the place of purchase for a free of charge replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.



ML Accessories Limited LU5 4LT  
[www.mlaccessories.co.uk](http://www.mlaccessories.co.uk)



AKJUN21\_V2