

Contents

Section 1 Basic System Construction

Section 2 Installation

| | | |
|------|---|------|
| 2.1 | Before Installation | 2-2 |
| 2.2 | Unpacking | 2-4 |
| 2.3 | Names and Locations | 2-4 |
| 2.4 | Wall Mounting | 2-5 |
| 2.5 | Frame Ground Connection | 2-6 |
| 2.6 | Opening the Top Front Cover | 2-6 |
| 2.7 | Exchange Line Connection | 2-7 |
| 2.8 | Extension Connection | 2-10 |
| 2.9 | External Pager (Paging Equipment) Connection | 2-12 |
| 2.10 | External Music Connection | 2-13 |
| 2.11 | Paralleled Telephone Connection | 2-14 |
| 2.12 | Polarity Sensitive Telephone Connection | 2-15 |
| 2.13 | Printer and PC Connection | 2-16 |
| 2.14 | Location of Optional Cards | 2-19 |
| 2.15 | OGM/FAX Detection Card Installation | 2-19 |
| 2.16 | Doorphone and Door Opener Connection | 2-21 |
| 2.17 | Installing a 3-CO Line & 8 Ext Expansion Card (KX-TA62477) and 8 SLT Extn. Expansion Card (KX-TA62474) | 2-25 |
| 2.18 | Auxiliary Connection for Power Failure Transfer | 2-30 |
| 2.19 | Securing the Cords | 2-31 |
| 2.20 | Closing the Front Cover | 2-31 |
| 2.21 | Starting the System for the First Time | 2-32 |
| 2.22 | System Restart | 2-33 |
| 2.23 | System Data Clear | 2-34 |

Section 3 Features

| | | |
|---|--|------|
| A | Absent Message Capability | 3-2 |
| | Account Code Entry | 3-3 |
| | Alternate Calling – Ring/Voice | 3-3 |
| | Automatic Callback Busy (Camp-On) | 3-4 |
| | Automatic Exchange Line Access Number | 3-4 |
| | Automatic Route Selection (ARS) | 3-5 |
| B | Busy Extension Signalling | 3-10 |
| C | Call Barring | 3-11 |
| | Call Barring — Extension Lock Boundary Class | 3-13 |
| | Call Barring for System Speed Dialling | 3-13 |
| | Call Barring Override by Account Codes | 3-14 |
| | Call Forwarding | 3-15 |
| | Calling Party Control (CPC) Signal Detection | 3-15 |
| | Call Park | 3-16 |
| | Call Pickup | 3-17 |
| | Call Splitting | 3-17 |

Contents

| | | |
|----------|--|------|
| | Call Transfer – to Exchange Line | 3-18 |
| | Call Transfer – to Extension..... | 3-18 |
| | Call Waiting | 3-19 |
| | Conference (3-party) | 3-20 |
| | Conference (5-party) | 3-21 |
| D | Data Line Security | 3-21 |
| | Date and Time Setting | 3-22 |
| | Direct In Line (DIL)..... | 3-22 |
| | Direct Inward System Access (DISA)..... | 3-22 |
| | Display Contrast Adjustment (KX-T7130 only)..... | 3-28 |
| | Distinctive Dial Tones | 3-28 |
| | Do Not Disturb (DND)..... | 3-29 |
| | Door Opener | 3-30 |
| | Doorphone Call | 3-30 |
| | DSS Console..... | 3-31 |
| E | Emergency Call | 3-32 |
| | Exchange Line Ringing Selection | 3-32 |
| | Executive Busy Override..... | 3-33 |
| | Extension Button Confirmation (KX-T7130 only)..... | 3-33 |
| | Extension Feature Clear | 3-34 |
| | Extension Group..... | 3-35 |
| | Extension Hunting | 3-36 |
| | Extension Lock..... | 3-36 |
| | Extension Password / System Password | 3-37 |
| | External Feature Access | 3-38 |
| F | Flexible Buttons..... | 3-39 |
| H | Handsfree Answerback..... | 3-40 |
| | Handsfree Operation..... | 3-40 |
| | Hold | 3-40 |
| | Host PBX Access..... | 3-41 |
| I | Intercept Routing | 3-42 |
| | Intercom Calling..... | 3-42 |
| L | Language Selection | 3-43 |
| | Limited Call Duration | 3-43 |
| | Line Access Keys | 3-43 |
| | Log-In/Log-Out | 3-44 |
| M | Message Waiting..... | 3-45 |
| | Microphone Mute | 3-45 |
| | Music on Hold / Background Music (BGM) | 3-46 |
| O | One-Touch Dialling | 3-46 |
| | Operator / Manager Extension | 3-47 |
| | Operator Call | 3-47 |
| | Outgoing Message (OGM)..... | 3-48 |
| | Outside Calling..... | 3-52 |

Contents

| | | |
|----------|--|------|
| P | Paging | 3-53 |
| | Parallelled Telephone Connection | 3-54 |
| | Personal Speed Dialling | 3-54 |
| | Pickup Dialling | 3-55 |
| | Polarity Reverse Detection | 3-55 |
| | Power Failure Transfer | 3-56 |
| | Preferred Line Assignment — Incoming | 3-56 |
| | Preferred Line Assignment — Outgoing | 3-57 |
| | Proprietary Telephone Setting Data Default Set | 3-57 |
| | Pulse to Tone Conversion | 3-58 |
| R | Recall | 3-58 |
| | Recall Button on a Single Line Telephone | 3-59 |
| | Receiving Calls | 3-59 |
| | Redial | 3-60 |
| | Ringing Pattern Selection | 3-60 |
| | Room Monitor | 3-61 |
| S | Secret Dialling | 3-62 |
| | Self-Extension Number Confirmation (KX-T7130 only) | 3-62 |
| | Station Message Detail Recording (SMDR) | 3-63 |
| | System Data Default Set | 3-64 |
| | System Speed Dialling | 3-65 |
| T | Timed Reminder | 3-65 |
| | Time (Day/Night/Lunch) Service | 3-66 |
| U | Uniform Call Distribution (UCD) | 3-67 |
| V | Voice Mail Integration for KX-TVP100 | 3-71 |
| | Volume Control | 3-74 |
| W | Walking COS | 3-74 |

Section 4 System Programming

| | | |
|------------|--|------------|
| 4.1 | Before System Programming | 4-2 |
| 4.2 | System Programming | 4-5 |
| | [000] Date and Time Setting | 4-5 |
| | [001] System Speed Dialling Entry | 4-5 |
| | [002] System Password | 4-6 |
| | [003] DSS Console Port Assignment | 4-7 |
| | [004] Paired Telephone Assignment for DSS Console | 4-7 |
| | [005] One-Touch Transfer Using a DSS Button | 4-8 |
| | [006] Time (Day/Night/Lunch) Service Changing Mode | 4-8 |
| | [007] Time (Day/Night/Lunch) Service Start Time | 4-9 |
| | [008] Operator Assignment | 4-9 |
| | [009] Extension Number Assignment | 4-10 |
| | [010] LCD Time Display Selection | 4-11 |
| | [011] System Speed Dialling Name Setting | 4-12 |
| | [012] Alternative Feature Numbering Plan | 4-13 |
| | [100] Hunting Group Set | 4-14 |

Contents

| | |
|--|------|
| [101] Hunting Type..... | 4-14 |
| [102] Voice Mail Port for KX-TVP100..... | 4-15 |
| [103] DTMF Integration for KX-TVP100..... | 4-16 |
| [104] Hold Mode Selection | 4-17 |
| [105] Conference Tone | 4-17 |
| [106] External Paging Access Tone | 4-18 |
| [107] DTMF Receiver Check | 4-18 |
| [108] Recall Mode for a Locked Extension | 4-18 |
| [109] CO Indicator Assignment..... | 4-19 |
| [110] Recall Key Mode..... | 4-19 |
| [111] Hold Music Selection..... | 4-20 |
| [112] DSS Console Indication Mode | 4-20 |
| [115] Extension Ringing Pattern Selection | 4-21 |
| [116] Conference Pattern Selection | 4-21 |
| [117] Call Pickup Tone | 4-22 |
| [118] Pulse Restriction | 4-22 |
| [119] Redialling after Pulse to Tone Conversion | 4-22 |
| [120] Bell Frequency | 4-23 |
| [121] Automatic Exchange Line Access Number Selection | 4-23 |
| [122] Automatic Rotation for Exchange Line Access..... | 4-23 |
| [123] Break Ratio | 4-24 |
| [124] SLT Ringing Mode Selection..... | 4-24 |
| [125] Call Barring Check for * and #..... | 4-24 |
| [126] DSS Off-Hook Mode | 4-25 |
| [127] Pickup Group Set | 4-25 |
| [200] Hold Recall Time | 4-26 |
| [201] Transfer Recall Time..... | 4-26 |
| [202] Call Forwarding Start Time | 4-27 |
| [203] Pickup Dial Delay Time..... | 4-27 |
| [204] Call Duration Count Start Time | 4-28 |
| [206] Dialling Start Time..... | 4-28 |
| [207] Recall Timing Range Selection..... | 4-29 |
| [208] Interdigit Time..... | 4-29 |
| [210] DTMF Time | 4-30 |
| [211] No Dial Disconnection..... | 4-30 |
| [212] Exchange Line Duration Time Limit..... | 4-31 |
| [213] Bell Off Detection | 4-31 |
| [300] Carrier Excepted Code Assignment..... | 4-32 |
| [301] Call Barring – System Speed Dialling Boundary Class | 4-32 |
| [302]-[305] Call Barring – Classes 2 through 5 Denied Codes..... | 4-33 |
| [306] Call Barring – Exception Codes | 4-34 |
| [309] Emergency Dial Number Set | 4-34 |
| [310] Account Codes | 4-35 |
| [311] Automatic Pause Insertion Codes | 4-35 |
| [312] Call Barring – Extension Lock Boundary Class | 4-36 |

Contents

| | |
|--|------|
| [350] ARS Selection | 4-37 |
| [351]-[354] Routes 1 through 4 Selection Codes (Leading Digits).. | 4-37 |
| [355]-[358] Routes 1 through 4 Exception Codes | 4-38 |
| [359] 1st Carrier Selection Code (BT Line Access Code)..... | 4-38 |
| [360] ARS Modification – Removed Digits..... | 4-39 |
| [361] ARS Modification – Added Number | 4-39 |
| [362] ARS Dial Tone Pattern Selection..... | 4-40 |
| [363] ARS Interdigit Time..... | 4-40 |
| [364] ARS Trunk Group..... | 4-41 |
| [381]-[384] Routes 1 through 4 Authorisation Codes..... | 4-42 |
| [385]-[388] Routes 1 through 4 Itemised Bill..... | 4-43 |
| [389] Itemised Bill Code Assignment | 4-43 |
| [400] Exchange Line Connection Assignment..... | 4-44 |
| [401] Dial Mode | 4-44 |
| [402] Pulse Speed Selection | 4-45 |
| [403] Host PBX Access Codes..... | 4-45 |
| [404] Trunk Group Assignment..... | 4-46 |
| [405]-[407] Flexible Outward Dialling Assignment —Day/Night/Lunch | 4-47 |
| [408]-[410] Flexible Ringing Assignment —Day/Night/Lunch | 4-48 |
| [411]-[413] Delayed Ringing Assignment —Day/Night/Lunch | 4-49 |
| [414]-[416] Exchange Line Mode —Day/Night/Lunch..... | 4-50 |
| [417] Pause Time | 4-51 |
| [418] Recall Time | 4-52 |
| [419] Automatic Designated Exchange Line Access | 4-52 |
| [420] Calling Party Control (CPC) Signal..... | 4-53 |
| [421] CPC Detection for Outgoing Calls | 4-54 |
| [422] Disconnect Time | 4-54 |
| [423] Exchange Line Ringing Pattern Selection | 4-55 |
| [424] Reverse (Polarity) Circuit Assignment | 4-56 |
| [500] DISA Incoming Dialling Mode Selection | 4-57 |
| [501] DISA Built-in Auto Attendant | 4-58 |
| [502] OGM Mode Selection..... | 4-59 |
| [503] FAX Connection..... | 4-60 |
| [504] DISA Delayed Answer Time | 4-60 |
| [505] DISA Waiting Time after OGM..... | 4-60 |
| [506] DISA Busy Mode..... | 4-61 |
| [507] DISA Intercept Mode..... | 4-61 |
| [508] DISA Ringing Time before Intercept | 4-62 |
| [509] DISA Ringing Time after Intercept | 4-62 |
| [510] DISA No Dial Mode | 4-63 |
| [513] Cyclic Tone Detection..... | 4-63 |
| [514] FAX Tone Detection | 4-64 |
| [515] Intercept Time for Internal DISA | 4-64 |

Contents

| | |
|--|------|
| [516] DISA Incoming Assignment | 4-65 |
| [517] DISA AA Wait Time | 4-65 |
| [519] DISA OGM Mute Time | 4-66 |
| [520] UCD Group | 4-66 |
| [521] UCD Busy Waiting Time | 4-66 |
| [522] UCD OGM Message Interval Time | 4-67 |
| [523] UCD Busy Mode..... | 4-67 |
| [524] UCD Intercept Mode..... | 4-68 |
| [525] UCD Ringing Time before Intercept | 4-68 |
| [526] UCD Ringing Time after Intercept | 4-68 |
| [600] Extension Group Assignment | 4-69 |
| [601]-[603] Call Barring – Class of Service Assignment —Day/Night/Lunch | 4-69 |
| [604] Extension Name Setting..... | 4-70 |
| [605] Account Code Entry Mode | 4-71 |
| [606] Call Transfer to an Exchange Line | 4-72 |
| [607] Call Forwarding to an Exchange Line | 4-72 |
| [608] Executive Busy Override | 4-73 |
| [609] Do Not Disturb Override | 4-73 |
| [610] Paralleled Telephone Connection..... | 4-74 |
| [611] TAM (Telephone Answering Machine) Extension | 4-74 |
| [612] Room Monitor Assignment..... | 4-75 |
| [613] Exchange Line Duration Time Limit Selection | 4-75 |
| [614] Internal Pulse Detection..... | 4-76 |
| [615] LCD Language Assignment..... | 4-77 |
| [700]-[702] Doorphone Ringing Assignment —Day/Night/Lunch .. | 4-78 |
| [703]-[705] Door Opener Assignment —Day/Night/Lunch | 4-79 |
| [706] Doorphone Ringing / Tone Pattern Selection | 4-80 |
| [707] Doorphone Access Tone Selection..... | 4-80 |
| [708] Doorphone Ringing Time | 4-81 |
| [709] Door Opener Time | 4-81 |
| [800] SMDR RS-232C Communication Parameters..... | 4-82 |
| [801] SMDR Parameter | 4-83 |
| [802] Incoming/Outgoing Call Selection for Printing..... | 4-83 |
| [803] Secret Speed Dialling / One-Touch Dialling Printing | 4-84 |
| [804] System Data Dump | 4-84 |
| [805] SMDR Account Code Selection | 4-85 |
| [806] SMDR Language Assignment..... | 4-86 |
| [998] ROM Version..... | 4-86 |
| [999] System Data Clear..... | 4-87 |

Contents

| | | |
|------------------|---------------------------|-----|
| Section 5 | Appendix | |
| 5.1 | Default Values | 5-2 |
| 5.2 | Specifications | 5-7 |
| Section 6 | Troubleshooting | |
| 6.1 | While Installing | 6-2 |
| 6.2 | While Connecting | 6-3 |
| 6.3 | While Operating | 6-4 |
| Section 7 | Programming Tables | |
| | Template | |