




Gold Heater
Operating Instructions



Models: HSIH 1000 and HSIH 800
Please Keep These Instructions For Future Reference

IMPORTANT: Ensure all instructions are read before use.

- Keep out of reach from children at all times.
- Ensure that your heater is disconnected and has been allowed to cool before cleaning or handling.
- Do not obstruct the heater or cover the heater in any way when the heater is in use.
- Ensure that the mains cable is not touching the outer casing of the heater.
- Ensure that this unit is only switched on once the installation process has been completed.
- Do not use an extension cable to power this unit as this could cause the unit to overheat and a risk of fire.
- Ensure that you do not touch the heater when in use always turn off the unit and allow to cool.
- Ensure that your electricity supply voltage corresponds with the stated voltage for this heater.
- Always ensure that the unit is disconnected from the mains power supply when fitting or replacing the halogen element.
- Ensure that the halogen element has cooled down before replacement.
- Do not handle the halogen element with bare hands as moisture can shorten the life of the element.


Technical Specification

<i>Voltage</i>	<i>AC230V-240V</i>
<i>Phase Supply</i>	<i>Single 230V-240V</i>
<i>Minimum Mounting Height From Floor</i>	<i>2.75 Metres</i>
<i>Minimum Distance From Ceiling</i>	<i>0.5 Metres</i>
<i>Minimum Distance From Side Walls</i>	<i>1.5 Metres</i>
<i>Unit Dimensions - W x H x D 1000W</i>	<i>345x250x170mm</i>
<i>Unit Dimensions - W x H x D 800W</i>	<i>275x245x150mm</i>
<i>Ingress Protection</i>	<i>IP54</i>
<i>Element Type</i>	<i>1000 Watt/800Watt</i>

Mounting & Positioning



Remove the mounting brackets by unscrewing the 2 bolts and nuts.



Ensure that the heater is mounted at a safe distance away from any flammable surface and that the unit is mounted on a non-flammable surface.



Once a suitable location has been selected, fix the bracket securely.




Position the heater to your desired angle using the bolts on either side of the bracket once positioned to a desired angle, ensure that the bolts are fully tightened.

Replacing the Halogen Element



Ensure that the unit has cooled and is switched off at the mains and unplugged. Remove the screws from the unit, these are located on the top of the units casing.




Carefully open the glass front and place onto a smooth flat surface.





Locate the halogen element into the lampholder, push at either end to affix into place. Ensuring that the element is not touched with bare hands.

Replacing the Halogen Element . Cont.



Once the halogen element has been replaced correctly locate the front of the unit back into place and tighten the screws ensuring a water tight seal is achieved.



Always make sure that the unit is plugged into a waterproof socket. If in any doubt consult a professional electrician.

Maintenance & Cleaning

- 1. Always ensure that the appliance is disconnected from the mains before any maintenance or cleaning is attempted.*
- 2. After approximately 100 hours it is recommended that the front cover of the unit is opened and the inside of the glass and reflector is cleaned with a lint-free cloth. Always make sure that the unit has been allowed to cool before this action is taken.*
- 3. If the inside of the glass or the reflector shows a milky colouring, this is normal due to internal vapours. To clean this open the front cover and clean the glass and the reflector with a lint free cloth.*

Note

All measurements & Dimensions of this product are approximate and due to the company's policy of research & development can be subject to change without prior notice.

*Always consult **a** qualified electrician*