



GuardCam[®] DECO

GUARDCAMDECO: COMBINED WI-FI SECURITY CAMERA LED FLOODLIGHT SYSTEM


QUICK START GUIDE



www.espuk.com




KIT CONTENT



Note:

For video recording, BE SURE TO use CLASS 10 memory card or above to have optimal performance and to avoid potential in-compatibility of other class memory card.

HARDWARE OVERVIEW



Note:

Press the reset button for 5 seconds, until the white LED is light up. The system will restore to factory default and you need to set up the camera again.



FRIENDLY REMINDER

Connect your smart phone to the Wi-Fi network that your device connect to. If the signal strength of your Wi-Fi router is weak, try to move it closer.

SETUP THE CAMERA

1. APP DOWNLOAD

Download and install the 'ESP GuardcamDECO APP to your device.




For iOS



For Android

2. Power Up The Camera For Wi-Fi Setup


- Power the camera temporarily or use any standard Micro USB Cable with USB power adaptor to connect to the bottom of the camera as shown below.
- Power on the camera and wait until the Blue LED indicator becomes steady on.
(This process would be finished within 45 seconds and make sure the LED is ashing in blue)
- For power setup procedure, please refer to ' Installation" section.
- This is only to setup the Wi-Fi of the camera. LED light will not turn on during this step.



3a. Direct Wireless Connection

- (1) Go to the Wi-Fi setting on your mobile device. Choose the Wi-Fi router with a prefix of HD-xxxxxx (xxxxxx=Camera ID numbers).
Enter the default password 12345678 and save the settings.
- (2) Launch the APP, tap to add camera.
- (3) Scan the QR code label on the back of the camera to bring up the DID information (CGXX-XXXXXX-XXXXXX), or manually type in the DID, including the dashes.
- (4) Name your camera (max. 20 characters).
- (5) Enter the security code:123456.
- (6) Tap save information and follow the in-app wizard to complete the setup process.

3b. Wi-Fi Setting



3b. The camera will be off-line for around 40 seconds to reboot for Wi connection. When camera connects to Wi-Fi router correctly, Green LED will stay ON.

3c. In the Wi-Fi setting of your smart phone/tablet, make sure the Wi-Fi router you are connecting to is the same as the camera. If not, manually assign to it.


Be sure to choose your local home Wi-Fi router on your local network in the ADVANCED SETTING. The system will begin to count down and reboot the system. The camera view will show on screen again after Wi-Fi setting has been updated.



INSTALLATION


Notice:

- For optimal performance , please install the lighting camera 2.5 meters height.
- Disconnect power at fuse or circuit breaker before proceeding to the installation.
- Recommend to have the installation distance between the lighting camera and the router to be 150 meters or less in case the transmission range of the router is not long enough for optimal Wi-Fi connection.



ETHERNET CONNECTION (OPTIONAL)

(1) Follow the below illustration to connect the ethernet cable if not using the Wi-Fi connection.



Note:


Wi-Fi setting may fail if you leave the ethernet cable connected. Please remove the cable after settings have been completed.





CAMERA SETUP INSTRUCTION


(1) Please make sure you have turn off the power from the breaker before this step.



(2) A) Make a small hole in the rubber pad to have AC power wire run into the junction box base.


B) Lead the wires to the front of the base, screw the wires firmly to the terminal blocks. Put the terminal blocks back into the base properly to protect it against water.

2










- (3) Fasten the junction box to the wall. Make sure that the UP sign is at the top.
- (4) Connect the power cable to the junction box.
- (5) Place the device on the junction box.
- (6) Fasten the screw by using the Phillips screw driver.



- (7) Adjust the tilting angle of camera by adjusting the screws on both side.
- (8) Loosen the screw on the back using hex key provided to adjust the pan angle. Screw it firmly when you done.
- (9) Once completed, turn on the power from the breaker and the lighting camera will power up. Wait for 1 minute for camera to connect to internet.
- (10) The LED light will be at its full brightness when initial start due to the regulation. You could adjust the brightness to prefer level once the camera has setup completed.
- (11) It is recommended to install the lighting camera at the at surface under the eave or position to have better waterproof protection.





APP OVERVIEW/LIGHTING SETTINGS

Camera List



- Add Camera
- Camera Setting
- Refresh
- Information


Live-View



- Tap here to turn on/off light
- Slide the bar to adjust the brightness of light
- Return to camera list
- Enable/Disable Siren
- Push to talk
- Video record
- Mute/Unmute
- Take a picture

Follow the steps below for Event Playback

1. Tap  and then the .
2. Select the time interval for the event list.
3. Tap to select the le for playback.
4. If you want to store the files in mobile device, tap  to download the le (Best while under Wi-Fi environment due to larger high definition data size).



Products with CE Marking comply with EMC Directive (2014/30/EU); Low Voltage Directive (2014/35/EU); RED (2014/53/EU); ROHS Directive (2011/65/EU) issued by the Commission of the European Community. Compliance with these directives implies conformity to the following European Norms:

EMC: EN 301 489

LVD: EN 60950

Radio: EN 300 328



If the camera system no longer functions or can no longer be repaired, it must be disposed of according to the valid statutory regulations. Disposal of spent batteries/accumulators:

You are required by law (Battery Ordinance) to return all spent batteries and accumulators. Disposing of spent batteries/accumulators with common household waste is prohibited! Batteries/accumulators that contain hazardous substances are marked with the symbols on the side. These symbols indicate that it is prohibited to dispose of these batteries/accumulators in the household waste. The abbreviations for the respective heavy metals are: Cd=cadmium, Hg=mercury, Pb=lead. You can return spent batteries and accumulators that can no longer be charged to the designated collection points in your community, outlets or wherever batteries or accumulators are sold. Following these instructions will allow you to fulfil the legal requirements and contribute to the protection of our environment!



GuardCam[®] DECO





Elite Security Products

Unit 7, Target Park, Shawbank Rd
Lakeside, Redditch B98 8YN



Telephone: 01527 51 51 50

Fax: 01527 51 51 43

email: info@espuk.com

E&OE - Errors and omissions excepted. B18

www.espuk.com

