




Kinetic Wireless Switch

Installation Instruction




Read instructions carefully before installation



Kinetic Wireless Switch



Component diagrams




- 1 Switch plate
- 2 double sided adhesive tape
- 3 Wall fixing plate
- 4 Cross shaped box fixing plate -QURCP (optional only- **not included**)

Specifications

Kinetic Wireless Switch Technical Parameters:

Power supply: Micro energy acquisition and self generating (no battery required)
Control distance*: 160m (outdoor), 30m (indoor)
Control method: pairing with Quinetic Controller for Kinetic Wireless Switch
Guaranteed 3 Years
May be used in bathrooms
For outdoor use mount in an IP rated enclosure
Permanently fixed or placed on wall using self adhesive 3M tape (supplied)



Every Quinetic product has passed the strict quality inspection before it leaves the factory. Quinetic provides 3 years warranty if installed & used in accordance with these instructions. Within the 3 years warranty period, Quinetic will be responsible for the repair, free replacement of parts or entire product.

* Distance comes from Quinetic laboratory test result. The actual distance in practical use might vary due to environmental difference.

Installation Methods

Three installation methods for wireless kinetic energy switch:

- 1 Adhesive installation method:
 - 1-1 Applicable environment: glass, marble, ceramic tile and other smooth surface
 - 1-2 Choose the installation position; clean the surface to ensure no oil/water etc.
 - 1-3 Take the double sided adhesive tape (included), paste the tape on the bottom of switch in accordance with the mark on the bottom (See diagram 1-1A-01)




diagram 1-1A-01

- 1-4 Place the switch in position required. The glue will be dry after 24 hours depending on conditions.

2 Plate installation method:

2-1 Applicable environment: flat wall such as normal lime wall, painted wall, etc...

2-2 To remove the fixing plate from the switch:

Step 1: Remove the outer frame from the switch. (refer to diagram 2-2A)



diagram 2-2A

Step 2: Remove the fixing plate by pushing it 5mm downwards then pull it out. (refer to diagram 2-2B)



diagram 2-2B

2-3 Screw the plate to the wall using appropriate fixings, the screws should be in the middle of the mounting holes. (refer to diagram 2-2C)




diagram 2-2C

2-4 Align the switch with the fixing plate, push back then down to fix in place. (refer to diagram 2-2D)




diagram 2-2D

2-5 Clip the outer frame onto the switch with the product logo at the bottom. (refer to diagram 2-2E)




diagram 2-2E

3 Box plate installation method

3-1 The Quinetic switch can be installed onto existing single wall boxes using the cross shaped fixing plate QURCP (**not included**).

3-2 Remove the fixing plate from the switch, steps as in 2-2

Step 1: Remove the outer frame from the switch. (refer to diagram 2-2A)
Step 2: Remove the fixing plate by pushing it 5mm downwards then pull it out. (refer to diagram 2-2B)

3-3 Connect the plate to the box using appropriate screws. Do not over tighten screws, this may cause the plate to buckle. Do not use torque greater than 18kgf. (refer to diagram 2-3A)




diagram 2-3A

3-4 Align the switch with the fixing plate, push back then down to fix in place. (refer to diagram 2-2D)

3-5 Clip the outer frame onto the switch with the product logo at the bottom. (refer to diagram 2-2E, 2-3B)




diagram 2-3B

Kinetic Wireless Switch Dimensions

