

INSTALLATION & MAINTENANCE MANUAL

PRCLED / PRCLED4

GENERAL INSTRUCTIONS

These instructions should be read carefully and retained after installation by the end user for future reference and maintenance.

These instructions should be used to aid installation of the following products: $\mbox{PRCLED} \ / \ \mbox{PRCLED4}$


SAFETY

- This product must be installed in accordance with the latest edition of the IEE Wiring Regulations (BS7671) and current Building Regulations. If in any doubt, consult a qualified electrician
- · Please isolate mains prior to installation or maintenance
- Check the total load on the circuit (including when this luminaire is fitted) does not exceed the rating of the circuit cable, fuse or circuit breaker
- · Please note the IP (Ingress Protection) rating of this product when deciding the location for installation
- · This product is for indoor use only
- · This product is Class I and must be earthed
- · This product is IP20 rated


INSTALLATION

Note - If this product is being used in conjunction with an external PIR or sensor, please confirm with the manufacturer of the sensors that they are compatible with LED luminaires.

- · Provide power to the required point of installation
- With the aid of a flat-head screwdriver, remove the end caps, squeeze the sides of the diffuser, and pull the diffuser away from the base (see Fig. 1)



- Mark the location of the fixing holes and drill the holes ensuring not to infringe with any gas / water pipes or electrical cables
- Feed the mains cable into the fitting, and secure to the surface
- Connect the luminaire to the mains supply ensuring the correct polarity is observed: L Live (brown),
 E Earth (green/yellow), N Neutral (blue) (see Fig. 2). Two cables can be inserted into the push-fit terminal block in order to achieve loop in/loop-out wiring



- · Refit the diffuser and end caps
- · Switch on and check for correct operation

WARNING

This product must be disconnected from the circuit if subjected to any high voltage or insulation resistance testing. Irreparable damage will occur if this instruction is not followed.

GENERAL

This product contains a light source of energy efficiency class D to Regulation (EU) No 2019/2015.

This product contains a non-replaceable LED light source and a control gear which can be replaced by a professional



Clean with a soft dry cloth only, do not use aggressive cleaning products or solvents which may damage the product.

This product is non-dimmable.

This product should be dismantled for disposal when it reaches the end of its life. Please see website for dismantling instructions.

This product should be recycled in the correct manner when it reaches the end of its life. Check local authorities for where facilities exist.

WARRANTY

This product has a warranty of 5 years from date of purchase. Failure to install this product in accordance with the current edition of the IEE Wiring Regulations (BS7671), improper use, or removal of the batch code will invalidate the warranty. If this product should fail within its warranty period, it should be returned to the place of purchase for a free of charge replacement. ML Accessories does not accept responsibility for any installation costs associated with the replacement product. Your statutory rights are not affected. ML Accessories reserve the right to alter product specification without prior notice.



















ML Accessories Limited LU5 4LT www.mlaccessories.co.uk